

Move : M [range list] **New address**

This command can be used to *a block* of Memory to the new location of memory.

Examples:

Fill the locations of memory with a string “cyber security” starting at location 100h.
Move 1 Kbyte of memory that located at address 100 to the address 600

- M 100 4ff 600



```
C:\Users\Laptop\Desktop\NEWFOL~4\DEBUG.COM
-m 100 4ff 600
-d 100
0AE0:0100  C3 7B 98 33 C9 87 0E 3D-96 E3 F3 FF 06 3D 99 80 .<.3...=.....=..
0AE0:0110  3E 3B 99 00 75 35 33 D2-1E 8E 1E 1C 96 B4 40 CD >;..u53.....@.
0AE0:0120  21 1F BA F0 89 73 03 E9-4E FF 2B C8 74 D0 F6 06 !....s..N..+.t...
0AE0:0130  7D 98 80 74 39 F6 06 7D-98 20 75 0A 80 3E 3A 99 >...t9...>. u...>:..
0AE0:0140  00 75 BB 49 74 B8 BA 73-8B EB 23 33 D2 87 D1 B8 .u.lt...s...#3....
0AE0:0150  01 42 CD 21 A3 47 99 89-16 49 99 80 3E 2D 96 00 .B.!..G...I...>-..
0AE0:0160  74 9C B4 40 CD 21 72 5F-C6 06 4B 99 1A C3 E8 CE t...@.!r...K.....
0AE0:0170  0F FE 06 3A 96 80 3E 39-96 00 74 48 8B 1E 7B 98 ...:...>9...tH...<.
-d 600
0AE0:0600  C3 7B 98 33 C9 87 0E 3D-96 E3 F3 FF 06 3D 99 80 .<.3...=.....=..
0AE0:0610  3E 3B 99 00 75 35 33 D2-1E 8E 1E 1C 96 B4 40 CD >;..u53.....@.
0AE0:0620  21 1F BA F0 89 73 03 E9-4E FF 2B C8 74 D0 F6 06 !....s..N..+.t...
0AE0:0630  7D 98 80 74 39 F6 06 7D-98 20 75 0A 80 3E 3A 99 >...t9...>. u...>:..
0AE0:0640  00 75 BB 49 74 B8 BA 73-8B EB 23 33 D2 87 D1 B8 .u.lt...s...#3....
0AE0:0650  01 42 CD 21 A3 47 99 89-16 49 99 80 3E 2D 96 00 .B.!..G...I...>-..
0AE0:0660  74 9C B4 40 CD 21 72 5F-C6 06 4B 99 1A C3 E8 CE t...@.!r...K.....
0AE0:0670  0F FE 06 3A 96 80 3E 39-96 00 74 48 8B 1E 7B 98 ...:...>9...tH...<.
```

Unassemble: U [range address]

The command is used to convert machine instructions into 8086 assembly language. The Here's an example of how we can use U command:

- U 100 107



```
C:\Users\Laptop\Desktop\NEWFOL~4\DEBUG.COM
-e 100
0AE0:0100  C3.b8 7B.34 98.12 33.bb C9.78 87.56 0E.11 3D.d8
0AE0:0108  96.96 E3.
-u 100 107
0AE0:0100  B83412          MOV     AX,1234
0AE0:0103  BB7856          MOV     BX,5678
0AE0:0106  11D8           ADC     AX,BX
```

Using A command to apply all addressing mode

1. Register Addressing Mode
2. Immediate Addressing Mode
3. Memory Addressing Mode
4. String Addressing Mode
5. I/O Addressing Mode
6. Implied Addressing Mode

