

PRODUCTION **ENGINEERING – I**

Introduction to Production Technology

The production engineering is that part of Petroleum Engineering which attempts to maximize production (or injection) in a cost manner.

The appreciation of production engineering and methods of application are related directly and interpedently with other major areas of petroleum engineering such as Formation Evaluation, Drilling engineering and Reservoir Engineering.

The role of the Production Technologist is extremely broad. Currently within the operating companies in the petroleum industry, the role and responsibility does vary between companies but can be broadly said to be responsible for the production system.

The production system is a composite term describing the entire production process and includes the following principal components:-

- 1- The reservoir - it productive capacity and dynamic production characteristics over the envisaged life of the development.
- 2- The wellbore - the production interval, the sump and the fluids in the wellbor
- 3- Production Conduit - comprising the tubing and the tubing components
- 4- Wellhead, Xmas Tree and Flow Lines
- 5- Treatment Facilities.

In simple terms, the term "well completion" refers to the methods by which a newly drilled well can be finalized so that reservoir fluids can be produced to surface production facilities efficiently and safely. In general, the process of completing a well includes the following:

- A method of providing satisfactory communication between the reservoir and the borehole.
- The design of the tubulars (casing and tubing) which will be installed in the well.
- An appropriate method of raising reservoir fluids to the surface.
- The design and the installation in the well of various components used to allow efficient production, pressure integrity testing, emergency containment of reservoir fluids, reservoir monitoring, barrier placement, well maintenance and well kill.
- The installation of safety devises and equipment, which will automatically shut a well in the event of a disaster.

In general, a well is the communication link between the surface and the reservoir and it represents a large percentage of the expenditure in the development of an oil or gas field. It is of utmost importance that the well be "completed" correctly at the onset, in order that maximum overall productivity of the field may be obtained. The ideal completion is the lowest cost completion which will meet the demands placed on it during its producing lifetime.

Figure (1) shows the Elements of the production technology system:




Figure (1): Elements of the production technology system

Before knowing the classification of completion, must know the main objective from wells drilling as following:

- Exploration and evaluation wells: This type of wells is drill for exploration and evaluation.
- Production wells: The wells are drilled and completed for produce oil, gas and sometime water produce.
- Injection wells: The wells are drilled and completed for inject water or gas or chemical material and sometimes petroleum products.
- Measurement and observation wells: The wells are drilled and completed for observation the reservoir (reservoir fluid behavior, reservoir pressure, etc...).
- Special operation wells: The wells are drilled and completed for special operation such as to kill the below out well.

From the above definition it can be seen that the responsibilities of Production Technology cover primarily subsurface aspects of the system but they can also extend to some of the surface facilities and treatment capabilities, depending on the operating company. The role of the Production Technologist is one of achieving optimum performance from the production system and to achieve this the technologist must understand fully the chemical and physical characteristics of the fluids which are to be produced and also the engineering systems which will be utilized to control the efficient and safe production/injection of fluids. The importance of the production chemistry input has only recently been widely acknowledged. It is clear that the physico-chemical processes which take place in the production of fluids can have a tremendous impact on project economics and on both the production capacity and safety of the well. The main disciplines which are involved in Production Technology are:

- I. Fluid flow
- II. Reservoir dynamics
- III. Equipment design, installation, operation and fault diagnosis

Reservoir Drive Mechanisms

Ideally the hydrocarbons are recovered from the reservoir porous media by the assistance of the drive mechanisms whether it was natural or artificial. Drive mechanisms have two classifications:

Internal drive: Using the internal energy of the reservoir configuration.

External drive: Which involves the invasion of the pore spaces by a replacement fluid, this type of drive called "Secondary recovery or Enhanced oil recovery".

Internal drive:

This is known as primary recovery, which includes three drive mechanisms:

- A. Depletion or internal gas drive (See Figure -2)
- B. External gas cap drive (See Figure – 3)
- C. Water drive (See Figure – 4)

A- Depletion or internal gas drive:

The compressibility of oil and water is relatively small. As soon as production commences, it is accompanied by a rapid drop of pressure in the producing zone which soon reaches the bubble point of entrained gas. Initially, this gas is dispersed, but it rapidly expands and assists in displacing the oil. Eventually, however, the gas will start to form a gas front, which, having more mobility than the oil, will increase the production gas to oil ratios. This depletion or dissolved gas drive is characterized by a rapid decline in reservoir pressure and by the recovery of only a small percentage of the oil in situation, e.g. 5 to 20% maximum see figure - 5




Figure – 2: Internal Gas Drive

B- External gas cap drive

Where the oil has a gas cap, the gas cap pressure together with the pressure of gas in solution tends to maintain pressure in the reservoir much longer than depletion drive. Therefore, gas cap reservoirs have higher recovery rates e.g. 20 to 40% see figure - 5




Figure – 3: Gas Cap Drive

C- Water Drive

Water drive is characterized by large local deposits of water which expand as pressure is reduced in the reservoir. Eventually, recovery will decrease due to the greater mobility of the water front which eventually breaks through to the well-bore with increased water to oil ratios. Nonetheless, water drive is the most efficient of all the drive mechanisms and can produce recovery rates as high as 60% see figure - 5




Figure – 4: Water Drive




Figure – 5: Expected recovery from different drives

Radial Flow in the Reservoir:

Description of geometry is often possible only with the use of numerical simulators. For many engineering purposes, however, the actual flow geometry may be represented by one of the following flow geometries:

- I. Radial flow
- II. Linear flow
- III. Spherical and hemispherical flow

I. Radial Flow:

In the absence of severe reservoir heterogeneities, flow into or away from a wellbore will follow radial flow lines from a substantial distance from the wellbore. Because fluids move toward the well from all directions and coverage at the wellbore, the term radial flow is given to characterize the flow of fluid into the wellbore. Figure - 6 shows idealized flow lines and iso-potential lines for a radial flow system.




Figure – 6: Ideal Radial Flow into the Reservoir

II. Linear Flow

Linear flow occurs when flow paths are parallel and the fluid flows in a single direction. In addition, the cross sectional area to flow must be constant. Figure - 7 shows an idealized linear flow system. A common application of linear flow equations is the fluid flow into vertical hydraulic fractures as illustrated in Figure - 8.




Figure - 7: Linear Flow




Figure - 8: Ideal Linear Flow into Vertical Fracture

III. Spherical and Hemispherical Flow

Depending upon the type of wellbore completion configuration, it is possible to have a spherical or hemispherical flow near the wellbore. A well with a limited perforated interval could result in spherical flow in the vicinity of the perforations as illustrated in Figure - 9. A well that only partially penetrates the pay zone, as shown in Figure - 10, could result in hemispherical flow. The condition could arise where coning of bottom water is important.




Figure - 9: Spherical Flow due to Limited Entry




Figure - 10: Hemispherical Flow

FLUID FLOW EQUATIONS

Darcy's Law

The fundamental law of fluid motion in porous media is Darcy's Law. The mathematical expression developed by Henry Darcy in 1856 states the velocity of a homogeneous fluid in a porous medium is proportional to the pressure gradient and inversely proportional to the fluid viscosity. For a horizontal linear system, this relationship is:

$$v = \frac{q}{A} = -\frac{k}{\mu} \frac{dp}{dx}$$

v is the apparent velocity in centimeters per second and is equal to q/A , where q is the volumetric flow rate in cubic centimeters per second and A is total cross-sectional area of the rock in square centimeters. In other words, A includes the area of the rock material as well as the area of the pore channels. The fluid viscosity, μ , is expressed in centipoise units, and the

Pressure gradient, dp/dx , is in atmospheres per centimeter, taken in the same direction as v and q . The proportionality constant, k , is the permeability of the rock expressed in Darcy units.

The negative sign in the equation is added because the pressure gradient is negative in the direction of flow.

For a horizontal-radial system, the pressure gradient is positive and Darcy's equation can be expressed in the following generalized radial form:

$$v = \frac{q_r}{A_r} = \frac{k}{\mu} \left(\frac{\partial p}{\partial r} \right)_r$$

Where

q_r = volumetric flow rate at radius r

A_r = cross-sectional area to flow at radius r

$(\partial p / \partial r)_r$ = pressure gradient at radius r

v = apparent velocity at radius r

The cross-sectional area at radius r is essentially the surface area of a cylinder. For a fully penetrated well with a net thickness of h , the cross-sectional area A is given by:

$$A_r = 2 \pi r h$$

Linear Flow of Incompressible Fluids

In the linear system, it is assumed the flow occurs through a constant cross-sectional area A, where both ends are entirely open to flow. It is also assumed that no flow crosses the sides, top, or bottom as shown in Figure -11 below:\




Figure - 11: Linear Flow Model

If an incompressible fluid is flowing across the element dx, then the fluid velocity v and the flow rate q are constants at all points. The flow behavior in this system can be expressed by the differential form of Darcy's equation and integrating over the length of the linear system gives

$$\frac{q}{A} \int_0^L dx = -\frac{k}{\mu} \int_{p_1}^{p_2} dp$$

$$q = \frac{kA(p_1 - p_2)}{\mu L}$$

OR

It is desirable to express the above relationship in customary field units

$$q = \frac{0.001127 kA(p_1 - p_2)}{\mu L}$$

Where:

q = flow rate, bbl/day

k = absolute permeability, md

p = pressure, psia

μ=viscosity, cp

L = distance, ft

A = cross-sectional area, ft²

Example: An incompressible fluid flows in a linear porous media with the following properties:

$$\begin{array}{lll} L = 2000 \text{ ft} & h = 20' & \text{width} = 300' \\ k = 100 \text{ md} & \phi = 15\% & \mu = 2 \text{ cp} \\ p_1 = 2000 \text{ psi} & p_2 = 1990 \text{ psi} & \end{array}$$

Calculate:

- Flow rate in bbl/day
- Apparent fluid velocity in ft/day
- Actual fluid velocity in ft/day

Solution:

Calculate the cross-sectional area A:

$$A = (h) (\text{width}) = (20) (100) = 6000 \text{ ft}^2$$

- Calculate the flow rate from Equation 6-14:

$$q = \frac{(0.001127)(100)(6000)(2000 - 1990)}{(2)(2000)} = 1.6905 \text{ bbl/day}$$

- Calculate the apparent velocity:

$$v = \frac{q}{A} = \frac{(1.6905)(5.615)}{6000} = 0.0016 \text{ ft/day}$$

- Calculate the actual fluid velocity:

$$v = \frac{q}{\phi A} = \frac{(1.6905)(5.615)}{(0.15)(6000)} = 0.0105 \text{ ft/day}$$

Radial Flow of Incompressible Fluids

In a radial flow system, all fluids move toward the producing well from all directions. Before flow can take place, however, a pressure differential must exist. Thus, if a well is to produce oil, which implies a flow of fluids through the formation to the wellbore, the pressure in the formation at the wellbore must be less than the pressure in the formation at some distance from the well.

The pressure in the formation at the wellbore of a producing well is known as the bottom-hole flowing pressure (flowing BHP, P_{wf}). Consider Figure - 12 which schematically illustrates the radial flow of

an incompressible fluid toward a vertical well. The formation is considered to have a uniform thickness h and a constant permeability k . Because the fluid is incompressible, the flow rate q must be constant at all radii. Due to the steady-state flowing condition, the pressure profile around the wellbore is maintained constant with time. Let P_{wf} represent the maintained bottom-hole flowing pressure at the wellbore radius r_w and p_e denote the external pressure at the external or drainage radius. Darcy's equation as described earlier can be used to determine the flow rate at any radius r :

$$v = \frac{q}{A_r} = 0.001127 \frac{k}{\mu} \frac{dp}{dr}$$




Figure - 12: Radial Flow Model

Frequently the two radii of interest are the wellbore radius r_w and the external or drainage radius r_e . Then:

$$Q_o = \frac{0.00708 kh (p_e - p_w)}{\mu_o B_o \ln (r_e/r_w)}$$

where Q_o = oil, flow rate, STB/day
 p_e = external pressure, psi
 p_{wf} = bottom-hole flowing pressure, psi
 k = permeability, md
 μ_o = oil viscosity, cp
 B_o = oil formation volume factor, bbl/STB
 h = thickness, ft
 r_e = external or drainage radius, ft
 r_w = wellbore radius, ft

To account for the convergence effects of flow, a simplified model based upon the assumption of radial flow to a central well located in the middle of a cylindrical reservoir unit is assumed as shown in Figure - 13 below:




Figure 13: Radial Inflow Model

The model assumes:

- The reservoir is horizontal and of constant thickness h .
- The reservoir has constant rock properties of ϕ and K .
- Single phase flow occurs to the well bore.
- The reservoir is circular of radius r_e .
- The well is located at the center of the reservoir and is of radius r_w .
- The fluid is of constant viscosity μ .
- The well is vertical and completed open hole, i.e. fluid enters the wellbore through the total height h .

Completion Design Consideration

Production technology contributes substantially as one of the major technical functions within an operating company and in particular, to its economic performance and cashflow. As with any commercial venture, the overall incentive will be to maximize profitability and it is in this context that the operations for which the production technologist is responsible, are at the sharp end of project economics. The objectives of an oil company operation could be broadly classified, with respect to two complimentary business drivers, namely:

- (a) Maximizing the magnitude of and accelerating cash flow
- (b) Cost minimization in terms of cost/bbl.

Total cost minimization may not be recommended.

- 1- Cashflow: The overall objectives would ideally be to maximize both cashflow and recoverable reserves. This would normally require maintaining the well in an operational state to achieve
 - maximum production rates
 - maximum economic longevity
 - minimum down time

This is shown in Figures 14 & 15 bellow:




Figure - 14




Figure - 15

Figures (14 & 15): Economic phase of field development and input from production engineer

- 2- Cost: In this category there would be both fixed and direct costs, the fixed costs being those associated by conducting the operation and the direct or variable costs being associated with the level of production and the nature of the operating problems. The latter costs are therefore defined in terms of cost per barrel of oil produced. On this basis the production technologist would seek to:
- Minimize capital costs
 - Minimize production costs
 - Minimize treatment costs
 - Minimize workover costs

From the above, the bulk of the operations for which the production technologist is responsible or has major inputs to, are at the sharp end of ensuring that the company's operations are safe, efficient and profitable. There for before a production well is drilled, a great deal of planning must be undertaken to ensure that the design of the completion is the best possible. A number of factors must be taken into account during this planning stage, which can broadly be split into the objective of well drilling, reservoir considerations and mechanical considerations.

Objective of well drilling

The objective of well drilling is very important factor in well completion design, may be the purpose from well drilling is clear from beginning or changed with time (a certain well completed as producing well then after that convert to injection well or observation well depend on the reservoir conditions).

Reservoir considerations

- Natural rock reservoir

The geological and experimental studies that conduct to delineate the nature of rock reservoir (type of rock, including fault, reservoir permeability, etc...) is important to select the adequate completion design.

- Producing rate

To provide maximum economic recovery is often the starting point for well completion design. Among other factors producing rate should determine the size of the producing conduit.

- Multiple reservoirs

Multiple reservoirs penetrated by a well pose the problem of multiple completions in one drilled hole. Possibilities include multiple completions inside casing separated by packers, or several strings of smaller casing cemented in one borehole to provide in effect separate wells. Other possibilities include commingling of hydrocarbons from separate reservoir downhole, or drilling several boreholes from one surface location.

- Reservoir drive mechanism

Reservoir drive mechanism may determine whether or not the completion interval will have to be adjusted as gas-oil or water-oil contacts move. A water drive situation may indicate water production problems. Dissolved gas and gas drive reservoirs usually mean declining productivity index and increasing gas-oil ratio.

- Secondary recovery requirements

Secondary recovery needs may require a completion method conducive to selective injection or production. Water flooding may increase volumes of fluid to be handled. High temperature recovery processes may require special casing and casing cementing materials.

- Stimulation

Stimulation may require special perforating patterns to permit zone isolation, perhaps adaptability to high injection rates, and a well hookup such that after the treatment the zone can be returned to production without contact with killing fluids.

- Sand control

Sand control problems alone may dictate the type of completion method and maximum production rates. On the other hand, reservoir fluid control problems may dictate that a less than desirable type of sand control be used.

- Artificial lift

Artificial lift may mean single completions even where multiple zones exist.

- Workover requirements
Workover frequencies, probably high where several reservoirs must be drained through one wellbore, often dictate a completion conducive to wireline or through-tubing type recompletion systems.

Mechanical considerations

The mechanical configuration or "well hookup" is often the key to being able to deplete the reservoir effectively, monitor downhole performance, and modify the well situation when necessary. The mechanical configuration of the well is the key to being able to do what ought to be done in the well from the standpoint of controlling the flow of reservoir fluids, oil, gas, and water.

- Functional requirements
- Operating conditions
- Component design
- Component reliability
- Safety

KEY SUBJECT AREAS IN PRODUCTION ENGINEERING

Production technology is both a diverse and complex area. With the on-going development of the Petroleum Industry the scope of the technological activities continues to expand and as always increases in depth and complexity. It is however, possible to identify several key subject areas within Production Technology namely:-

- Well Productivity
- Well Completion
- Well Stimulation
- Associated Production Problems
- Remedial and Workover Techniques
- Artificial Lift / Productivity Enhancement
- Surface Processing

Methods of completion:

In the development of a hydrocarbon reservoir, a large number of wells are drilled and require to be completed, to allow the structure to be depleted. However, the drilling and completion operations are crucial to the long term viability of the wells in meeting the specified objectives. The design and completion of both production and injection wells are required to satisfy a number of objectives including:

- Provision of optimum production/injection performance.

- Ensure safety.
- Maximize the integrity and reliability of the completion over the envisaged life of the completed well
- Minimize the total costs per unit volume of fluid produced or injected, i.e. minimize the costs of initial completion, maintaining production and remedial measures.

The fundamental design of a completion consists of four principal decision areas, namely:

- 1. Specification of the bottomhole completion technique.
- 2. Selection of the production conduit.
- 3. Assessment of completion string facilities.
- 4. Evaluation of well performance / productivity-injectivity

These four decision areas, as shown in Figure - 16, should provide a conceptual design for the completion of the wells. However, this design process normally is initiated on the basis of data from exploration wells and considerable uncertainty may exist as to the validity and accuracy of that data. Thus a number of alternative designs for well completions will normally be selected and retained as a contingency.




Figure - 16: Completion Design Strategy

Basically there are three main methods of completing a well which are:

- 1- Open-hole completion
- 2- Cased-hole completion
- 3- Liner completion; this completion can be include two types:

- a- Screen and liner completion.
- b- Perforated liner completion.

1- **Open-hole Completion:**

The simplest approach to bottomhole completion would be to leave the entire drilled reservoir section open after drilling, the production casing is set on top of producing zone before drill the production formation that contain the hydrocarbon fluids, then after casing was cemented, producing formation drilled, see figure - 17. Generally open-hole has greater application in carbonate zones.




Figure - 17: Open-hole Completion

Advantages;

- 1- Adaptable to special drilling techniques to minimize formation damage or to prevent lost circulation into the producing zone.
- 2- No perforating expense.
- 3- Log interpretation is not critical since entire interval is open
- 4- Full diameter opposite pay.
- 5- Can be easily deepened.
- 6- Easily converted to liner or perforated completion

Limitation;

- 1- Excessive gas or water production difficult to control.
- 2- Selective critical section in production zone to fracturing or acidizing more difficult.
- 3- May require frequent well-bore cleanout.
- 4- Requires more rig time on completion

2- Cased-hole completion:

The production casing is cemented through producing zone and perforated, see figure - 18.




Figure - 18: Cased-hole Completion

Advantages;

- 1- Excessive gas or water production can be controlled more easily.
- 2- Can be selectively stimulated.
- 3- Log and formation samples available to assist in decision to set casing or abandon.
- 4- Full diameter opposite pay.
- 5- Can be easily deepened.
- 6- Will control most sand, and is adaptable to special sand control techniques.
- 7- Adaptable to multiple completion techniques.
- 8- Minimum rig time on completion.

Limitation;

- 1- Cost of casing cement and perforating for long zones may be significant.
- 2- No adaptable to special drilling techniques to minimize formation damage.
- 3- Log interpretation is critical for most of logs except production logging.

Well productivity is less than productivity of open-hole well completion.

Liner completion:

I. Screen and Liner completion.

The production casing is set on top of producing zone, than the screen and the liner is set through producing zone, see figure - 19.

Advantages;

- 1- Adaptable to special drilling techniques to minimize formation damage or to prevent lost circulation into the producing zone.
- 2- No perforating expense.
- 3- Log interpretation is not critical since entire interval is open
- 4- Do not require frequent well-bore cleanout.
- 5- Will control most sand, and is adaptable to special sand control techniques.

Limitation;

- 1- Excessive gas or water production difficult to control.
- 2- Selective critical section in production zone to fracturing or acidizing more difficult.
- 3- Wellbore deepened is not easy.
- 4- Requires more rig time on completion.




Figure - 19: Liner Completion

II. Perforated Liner completion

The production casing is set on top of producing zone, then the producing zone was drilled after that the liner is set and cemented through producing, then perforated, see figure - 18.

Advantages;

1. Adaptable to special drilling techniques to minimize formation damage or to prevent lost circulation into the producing zone.
2. Gas and water production easy to control.
3. Selective critical section in production zone to fracturing or acidizing more easy.
4. Can be easily deepened.
5. Will control most sand because the liner obstructed sand movement, and is adaptable to special sand control techniques.

Limitation;

- 1- Cost of casing cement and perforating for long zones may be significant.
- 2- Log interpretation is critical for most of logs.
- 3- Requires more rig time on completion.
- 4- Difficult conduct good cement operations for liner compare with the first stage of casing cementing.

SELECTION OF THE FLOW CONDUIT BETWEEN THE RESERVOIR AND SURFACE

There are a number of optional methods by which fluid which enters the wellbore will be allowed to flow to surface in a production well, or to the formation in an injection well. In the selection of the method, a range of considerations may influence the choice including: cost, flow stability, ability to control flow and ensure well safety or isolation; ensuring that the integrity of the well will not be compromised by corrosion or erosion. In the case of multizone reservoir, the zonal characteristics will determine to a large extent the flow system selected.

However, for a single zone completion, the following alternatives exist:

- ✓ Tubingless casing flow.
- ✓ Casing and tubing flow.
- ✓ Tubing flow without annular isolation.
- ✓ Tubing flow with annular isolation.

- ⊃ **Tubingless Casing Flow:** This type of completion use in wells produces with high production rates and medium or low closed, flowing pressures. See figure - .20




Figure - 20: Tubingless Completion

- ⊃ **Casing and Tubing Flow:** In this type of completion the well produce through annulus and tubing in same time, but the production rate in this type being less than in type of producing through production casing. See figure - 21. Valid reasons for tubing may include:

- 1- Better flow efficiency.
- 2- Permit circulation of kill fluids, corrosion inhibitors or paraffin solvents.
- 3- Provide multiple flow paths for artificial lift system.
- 4- Protect casing from corrosion, abrasion, or pressure.

5- Provide indicate of monitoring bottom-hole flowing pressure.




Figure - 21: Casing and Tubing Flow

Tubing Flow without Annular Isolation: In situations where annular flow in a casing-string completion would result in excessive phase slippage with consequent increased flowing pressure loss and potential instability, the consideration could be given to merely closing the annulus at surface and preventing flow. However, in reservoirs where the flowing bottomhole pressure is at or below the bubble point, gas as it flows from the formation to the tubing tailpipe will migrate upwards under buoyancy forces and some gas will accumulate in the annulus. This will result in an increase in the casing head pressure at surface. In this type of completion the casing is exposed continuously to produce fluid with the possibilities of erosion or corrosion. This, coupled with the potential for annular heading, suggests that unless annular flow is required then the annulus should not be left open to production, despite its simple design.

- **Tubing Flow with Annulus Isolation:** For cases where a large cross sectional area for flow is not necessary, then an open annulus can cause complications as discussed in 2.3 above. Therefore, in the majority of cases where tubing flow will take place, the annulus is normally isolated by the installation of a packer. The packer has a rubber element which when compressed or inflated will expand to fill the annulus between the tubing and the casing. The packer is normally located as close to the top of the reservoir as possible to minimize the trapped annular volume beneath the packer and hence the volume of gas which could accumulate there. However, if the packer is installed, the ability to U-tube or circulate fluid between the tubing and annulus is removed. If such a circulation capability is required then it is necessary to install a tubing component which will allow annulus communication or alternatively rely upon the ability to perforate the tubing which consequently would necessitate tubing replacement prior to the recommencement of

production. In both cases, the circulation point is normally as deep in the well as possible, but above the packer. This completion system is by far the most widely used and offers maximum well security and control. See Figure - 22 below:



Figure - 22: Tubing Flow with Annulus Isolation

Completion String

For any completion string we can define a range of operations or capabilities which may be required. Some of the capabilities are considered to be essential, such as those providing operational security or safety, whilst others can provide improved performance or flexibility. However, as the degree of flexibility provided by the completion is increased, the more complex is the design process and normally a sophisticated design will result which includes a large number of string components.

Basic completion string functions and facilities

The basic facilities provided by a completion string must allow it to continue the production or injection of fluids over as long a period as possible without major intervention to conduct well repairs. Further, at all times, the design must ensure the safe operation of the well and reliably allow for its shutdown in a variety of situations.

The completion string, production casing and wellhead must act as a composite pressure system which prevents formation fluids and pressure escaping from the reservoir except via the production tubing and the Xmas Tree into the surface processing facilities.

The following are considered to be the essential attributes for the majority of completion string installations:

- A. The ability to contain anticipated flowing pressure and any hydraulic pressures which may be employed in well operations and conduct fluid to surface (production) or the reservoir (injection wells) with minimal flowing pressure loss and optimal flow stability.
- B. The ability to isolate the annulus between the casing and the production tubing if flow instability is likely or it is desirable to minimize reservoir fluid contact with the production casing.
- C. The ability to affect downhole shut-in either by remote control or directly activated by changing well flowing conditions, in the event that isolation at surface is not possible.
- D. A means to communicate or circulate (selectively when required) between the annulus and the tubing.
- E. A provision for physical isolation of the tubing by the installation of a plug to allow routine isolation e.g. for pressure testing of the tubing.

Figure - 23 bellow is showing the general completion string components:




Figure - 23: General well completion string

Conventional tubular configurations:

The conventional completions methods consist of production casing have outside diameter greater than 4 ½ inch, and include this is because that there are sizes production tubing vary to reach 4 ½ inches;

Single-zone completion

Factors leading to selection of single-zone “conventional” completions:

- 1- High production rates.
- 2- Corrosive well fluids.
- 3- Operator tradition.
- 4- High pressures governmental policies.

Probability of well competition for single-zone depending on objectives from well drilling, and that include:

Well produce through production casing

This type of completion use in wells produce with high production rates and medium or low closed, flowing pressures. See figure - 24:




Figure - 24: Well produce through production casing

Well produce through production casing and production tubing

In this type of completion the well produce through annulus and tubing in same time, but the production rate in this type being less than in type of producing through production casing. See figure - 25. Valid reasons for tubing may include:

- 6- Better flow efficiency.
- 7- Permit circulation of kill fluids, corrosion inhibitors or paraffin solvents.
- 8- Provide multiple flow paths for artificial lift system.
- 9- Protect casing from corrosion, abrasion, or pressure.
- 10- Provide indicate of monitoring bottom-hole flowing pressure.





Figure – 25: Well produce through production casing and production tubing

Well produce by artificial lift

In this type the well produce by pumping, where the tubing run in hole with pump seating nipple to depth below working fluid level in well, see figure - 26.



Well produce through production tubing

The well completed by using tubing and single production packer, in this completion the maximum potential of well to produce by high flow rate impossible, compare with the well produce through production casing and the well produce through production casing and production tubing, see figure - 27. A packer should be run only where it accomplishes a valid objective such as:

- 1- Improve or stabilize flow.
- 2- Protect casing from well fluids or pressure however, it should be recognized that use of a packer may increase pressure on casing in the event of a tubing leak.
- 3- Contain pressure in conjunction with an artificial lift system or safety shut-in system.
- 4- Hold on annular well-killing fluid.




Figure - 27: Well produce through production tubing

Single- well with alternate completion

This type is used, when the well penetrate two producing formations. The alternate produce formation perforation at the primary well completion, then isolate by using dual production packer, the alternate formation started to produce after the lower producing formation depleted by perforating the part of tubing in front of alternate formation, see figure - 28. Blast joint used in tubing part in front of alternate producing formation to resist the scratch that cause by produce fluids, because the blast joint have thick wall.




Figure - 28: Single- well with alternate completion

Multiple-zone completion

Factors leading to selection of multiple completions:

- 1- High producing rate
- 2- Faster payout
- 3- Multi-reservoir control equipments

Numerous configurations are possible utilized single or multiple strings of tubing;

Dual completion-Single string-single packer

There is both tubing and annulus flow, see figure - 29. This is the lowest cost conventional dual.

Limitations

- 1- Upper zone cannot be produced through tubing, unless lower zone is blanked off.
- 2- Casing subject to pressure and corrosion.
- 3- Only lower zone can be artificially lifted.
- 4- Upper zone sand production may stick tubing.
- 5- Work-over of upper zone requires killing lower zone.

Cross-over dual completion-Single string-dual packer

Again, There is both tubing and annulus flow, see figure -30. Advantage is that cross-over choke permits upper zone to be flowed through tubing.

Limitations

- 1- Casing subject to pressure and corrosion.
- 2- Must kill both zones for work-over of upper zone.
- 3- Any zones impossible can be artificially lifted.




Figure - 29: Dual completion-Single string-single packer

Dual completion-Parallel string-multiple packer

This is shown in figure - 31.

Advantages

- 1- Can lift several zones simultaneously.
- 2- Concentric tubing and wire line work-over practical in all zones.

Limitations

- 1- High cost.
- 2- Susceptibility to tubing and packer leaks.
- 3- Hesitation to perform stimulation treatments or work-over of individual zones.




Figure - 31: Dual completion-Parallel string-multiple packer

Parallel dual completion with two alternate completions.

This is shown in figure - 32.

Limitations

Difficult of treating or even reperforating individual zones unless well is killed and tubing is pulled




Figure - 32: Parallel dual completion with two alternate completions

Triple completion

In this completion design, two or three production tubing used with production packers, see figure - 33. In this type could produce with high production rates in one well, that make faster payout.

Limitations

1- Difficult made this completion.

May be communication occur between the fluids inside well, that produce from the three formations




Figure – 33: Triple completion

Completion Equipment

1- Production casing

Production casing is the last casing, which runs in hole then seated and cemented. In some completions design the producing fluids produce through production casing, also run through it production tubing and production packer. The different types of casing are classified according to API standard classification. Selecting of casing type depending on completion programmer factors and operating condition.

2- Production Tubing

The production tubing runs in hole for production and well control purpose, and to run in hole measurement instrument through it. There are several types of tubing according to standard API.

3- Liner

Liner is part of casing which hanger in well, it doesn't run from surface. Used to satisfy two purposes:

- 1- Reduce the cost, which can be used as alternative to casing run from surface, when the casing was damaged.
- 2- Used in sand control and gas coning.

4- Production packer

Generally, production packers are classified into two types; permanent packer (this type could not pull it out of hole, unless milling it then cleanout) and retrievable packer (this type could pull it out of hole mechanically and can used it again). The main purpose from using packer is to isolate the annulus from production zone (see figure –34 for the major components in production packer), and it is useful to the following matters;

- 1- Protection the upper parts of casing from high pressure, and from any reaction with the fluids that cause corrosion of casing in cases of production, injection and stimulation.
- 2- Protection the well form any leaks occur in casing.
- 3- Using in conjunction with subsurface safety valves (SSSV) to provide the safety.
- 4- To hold kill fluids or treating fluids in casing annulus.




Figure - 34: Major Components of Production Packer

5- Sliding Sleeve

Sliding sleeve is a nipple seat above production packer, used to open production tubing above packer for fluids circulation operations and control on well in work-over operations. This nipple opened and closed by special tools run in well by slick-line through tubing.

6- Subsurface Control Equipment

This equipment involves:

- 1- Subsurface safety valves (SSSV) used inside tubing which plug the tubing (close in the well) at a certain depth in case the surface valves failed. Such as Ball valves and flapper valves. These valves can control directly and indirectly.
- 2- Bottom hole-chokes and regulator used to reduce well head flowing pressure to prevent hydrates (fluid freezing) in surface control equipment and surface flowing lines. This equipment used in wells has high pressure, such as Ground Seat Bean and Positive Orifice Bean.
- 3- Subsurface safety valves (chock valves) for injection wells, this valves used to prevent reverse flow (back flow, control on flow direction), such as stem and seat valve and ball valve.

7- Wellhead/Xmas Tree

The wellhead provides the basis for the mechanical construction of the well at surface. It provides for:

- Suspension of all individual casings and tubulars, concentrically in the well.
- Ability to install a surface closure/flow control device on top of the well namely:
 - Blow Out Preventer during drilling
 - X-mass tree for production and injection
- Hydraulic access to the annuli between casing to allow cement placement and between the production casing and tubing for well circulation.

The purpose of the Xmas tree is to provide valve control of the fluids produced from or injected into the well. The Xmas tree is normally flanged up to the wellhead system after running the production tubing. The wellhead provides the facility for suspending the casing strings and production tubing in the well. There are a number of basic designs for Xmas trees, one of the simplest is shown in Figure -35. Briefly, it can be seen that it comprises 2 wing valve outlets, normally one for production and the other for injection, e.g. well killing. Additionally, the third outlet provides vertical access into the tubing for wireline concentric conveyancing of wireline or coiled tubing tools.

The lower valve is the master valve and it controls all hydraulic and mechanical access to the well. In some cases, the importance of this valve to well safety is so great that it is duplicated. All outlets have valves which in some cases are manually operated or in the case of sophisticated platform systems and subsea wells are remotely controlled hydraulic valves operated from a control room.




Figure - 35: Simple Wellhead Assembly including Casing Spools and Xmas Tree

Production packer setting methods

1- Mechanical setting method

Production packer seated by moving production tubing in a certain direction, based on that there are three types of packers:

A- Weight-Set Packer

The weight set packer is economical and ideally suited to low pressure situation, this packer employ a slip and cone arrangement with the slips attached to a friction device such as drag springs or drag blocks. The friction device engages the casing and holds the slips stationary with respect to the remainder of the packer, see figure - 36.

The vertical movement of tubing causes the cone to move behind the slips and anchor the packer in the casing. Tubing weight is then applied to expand the packing element (rubber element). Release is affected by picking up tubing weight to pull the cone from behind the slips.




Figure -36: Weight set packer

B- Tension-Set Packer

Tension packers are frequently used in shallow wells where insufficient tubing weight is available to seal a weight-set packer. It are essentially set by pulling tension on the tubing by run the tubing upside, release is effected by supply tension (run downside the tubing weight).

This features renders the tension packer particularly suitable for water injection wells or stimulation work.

C- Rotational -Set Packer

These types of packers are set by rotate the production tubing and supply tubing weight in same time or by rotate only, Release or back of the packer is effected by rotate the tubing to right direction. It's better to use this type in vertical shallow or medium wells.

2- Hydraulic Setting method

The packer with production tubing runs in hole through casing to a certain depth, after that the packer set hydraulically by supply or increase the pressure gradually inside tubing. There is shear plug below the packer, which cause pressure increased inside tubing (close tubing end) during

packer setting operation, then it opened by drop steel segment or increased the pressure to critical value. There is another type of packers, which the tubing closed below packer by steel ball or equalizing check valve set in special nipple below packer. Principle advantage to use this type is: the tubing can be landed, Christmas tree installed, and well circulated with a light fluid or gas before setting the packer to initiate production without swabbing.

3- Electric setting method

By wire-line and electric cable the entire assembly packer is run in hole to the desired setting depth. An electrically detonated powder charge was exploded inside packer that causes movement of setting tools which set the packer, then the production tubing run in to engage with packer.

Well Completion Program

Well completion operations beginning after ending well drilling and cementing the production casing. The well completion operations is very important therefore, it should be take in account all risk and problems that predicted occurred on well in well completion program, and provide all important required equipment and tools, these operations done by used drilling or work-over rig, and sometimes need exist fire man in the location.

We will take simple well completion program for cased hole well to illustrate the operations steps;

- 1- Run in hole the last casing (production casing), land and cement it. At least wait for 72 hours to dry the cement. then install blow out preventers (BOP`s).
- 2- Run in hole adequate bit by drilling pipes to clean the well-bore from any residual cement, also to check the bottom hole (total depth). Circulating the drill mud inside the well to sure that well-bore be cleaning, then pull out of hole drilling pipes and bit.
- 3- Run in hole Cement Bond Log (CBL) to check the quality of cementing of production casing.
- 4- Run in hole production tubing to bottom hole, then displace drill mud by completion fluid through tubing until clean the well-bore from drill mud.
- 5- Observe the well behavior by notice any flow of completion fluid, that take indicate for any leaks in production casing.
- 6- In case of no leaks, and the well behavior is normal (static) after displace the mud, then the tubing is rise and hang to depth above the highest perforated about 30 meters. After that the well is observed to insure from the well and pressure stabilized.
- 7- Removed the BOP`s, and install the tubing head spool (donate).
- 8- Install X-mas tree and construct the valves, then test the X-mas and valve by work pressure for time at least 15 minute per valve.
- 9- Install special perforating equipment on well head, which include pressure control equipment and container that contain bullet and accessories.
- 10- Put the bullet gun in container, which the bullet is arranged according to perforating configuration and with respect to depth of the perforated zone.

- 11- After set the container on X-mas tree, the master valves is opened then the bullet gun run in hole to depth of the zone that will be perforated. In perforated operations, the casing joints are avoided to perforated which the casing joints locater are characterized by run in hole Casing Collar Locater (CCL) log.
- 12- The zone will perforate by bomb the bullet from surface by special control station, generally noticed increased the well head pressure after the perforated of the production zone.
- 13- Pull out of hole the bullet gun and accessories to surface and closed the X-mas valves, the well head pressure continued increased gradually.
- 14- The well head valves (tubing and annulus valves) linked to burn pipe to burn the fluid in burn pit.
- 15- The well opened to flow by small choke size for cleanout purpose, the hydrocarbons fluid was burned in burn pit that far about 300 meters from the well.
- 16- The burned of hydrocarbons was continued until the well cleaned from completion fluid or water or residual drill mud, and the well reached stabilized condition. Then the well closed and it will be ready to done evaluated tests.

Perforation

Perforating of Oil and Gas Wells

In the majority of completions, once the reservoir has been drilled, production casing or a liner is run into the well and cemented in place. To provide the communication path between the reservoir and the wellbore, it will be necessary to produce holes through the wall of the casing, the cement sheath and penetrate into the formation. This is accomplished by a technique called perforating.

The basic operation requires that a series of explosive charges are lowered into the well either on an electric conductor (wireline cable), or on tubing or drillstring, and when the charges are located at the required depth, they are detonated to produce a series of perforations through the wall of the casing and the cement sheath.

Since the perforations will hopefully provide the only communication between reservoir and wellbore, it is necessary to carefully design and execute the perforating operation, to provide the required degree of reservoir depletion control and maximize well productivity/injectivity.

Although technology is available insure good perforating in most wells, unsatisfactory perforating tends to be rule in many areas. The three most prevalent causes for poor perforating probably are:

- 1- A lack of understanding of the requirements for optimum perforating.
- 2- Inadequate control of gun clearance.
- 3- The rather widespread practice of a warding perforating job on the basis of price, rather than job quality.

Perforating Techniques

There are three main perforating methods of cased wells:

1- Bullet Perforators

Bullet guns have outside diameter 3 ¼ inch or larger, are applicable in the formation with compressive strength less than about 6000 psi. Bullet perforators in the 3 ¼ inch or larger size range, may provide deeper penetration than many jet guns in formations with less than about 2000 psi compressive strength.

This type could not used it through X-mas tree and tubing because the larger size of outsider diameter of bullet guns, therefore, it used under drill mud control and install BOP`s on well head. The Bullet guns run in hole by wire-line and connected with electric bomb instrument, when the bullet is shoot, its velocity reached about 3300 ft/sec and it penetrate the casing and formation to depth about 5 inch. The bullet loses velocity and energy when the gun clearance exceeds 0.5 inch.

2- Jet perforators

This type characterized small size of Jet guns (2 1/8, 1 11/16 inch), so it could use through X-mas and production tubing. Therefore, it is the better and more safety method used to perforate the wells. The bullet consist from a solid metal body moved at a high speed about 20000 ft/sec, which the solid material convert to liquid because the bomb wave high pressure, that make the bullet penetrate the casing and formation to depth about 12 inch behind the casing. Bullet density equal 4 bullet/ft of perforated zone.

3- Hydraulic perforators

Used to make a fracture in production casing and the formation behind the casing. The fracture create hydraulically by inject special liquid with high pressure and high inject velocity through small choke size (1/4 inch). Sometimes add to inject liquid solid material (like sand) to assist in penetration of casing and formation.

This method used to penetrate wells that drilled for water injection because this method creating large perforate, which does not plug easily due to the suspension in the injected water.

See figure - 37 for perforating techniques:




Figure - 37: Perforating Techniques

Effect of formation strength on perforator performance

As shown in figure - 38, jets penetrate deeper than bullets in hard formation. However, some best bullet guns may penetrate deeper than some jets in low compressive strength formations, particularly if guns are fired at zero clearance.

Figure - 39 shows that penetration of jets, bullets, and hydraulic perforator was reduced with increased compressive strength of formation penetrated. However, bullet penetration declined at a more rapid rate as rock strength increased.




Figure - 38: Effect of formation compressive strength on penetration efficiency of bullet and jet perforators




Figure - 39: Bullet, Jet and Hydraulic perforator performance in formations of various compressive strength

Perforation Charge Arrangement

In the preparation of a perforation gun, a number of charges are assembled on a carrier such that upon detonation they will yield a series of perforations into the formation. The arrangement provides for variation in the number of shots to be fired per unit interval, i.e. the shot density and the direction in which all, or individual, charges will be shot, i.e. the shot phasing.

The number of shots installed in a perforating gun varies from low shot density, e.g. less than 1 shot/ft, to higher shot densities of up to 16 shots/ft. The lower shot densities are normally adequate for production in reservoirs of moderate to high productivity or are selected for specific injection operations where flow control is required. The higher shot densities will provide improved inflow performance in all reservoirs but may only be significantly beneficial in reservoirs with a low vertical permeability or where severe local drawdown might give rise to formation sand collapse.

The orientation of perforations defined as the angular phasing can be:

- 1- 0° or in-line firing which can provide the minimum clearance for all perforation if the gun is positioned to fire on the low side of the hole.
- 2- 45° to 90° phasing which provides the nearest approximation to radial flow.
- 3- 180° phasing in either of the two planar directions.
- 4- 120° phasing either with all 3 shots firing at 120° to each other or omitting 1 charge such that the 2 shots fire at $+60^\circ$ and -60° angular phase.

The phase orientations are depicted in (Figure - 40). All perforation flow patterns are utilised. 90° phasing which provides the best radial depletion can be very effective when conducted with high shot densities. However, the selection of phasing will depend not only on shot densities but gun size, gun clearance, formation isotropy or anisotropy with respect to permeability. It is clear that for each shot density a number of options regarding phasing can exist, for example, 4 shots/ft can normally be fired at 0° , 90° or 180° phasing (Figure – 41).




Figure - 41: Perforation Shot Phase Pattern




Figure- 42: Perforation shot Density: Example of four shots/foot in line firing and 90° phasing

Perforating Fluid

Before perforation operators, the well should fill with a fluid does not cause any formation damage when it connect with produce formation. The perforation should done at formation pressure lager than hydrostatic pressure. There are different types of perforating fluid as following;

- 1- Salt water (Brine) or Oil; when used purity fluid, it will do not cause perforate plug. But when the perforation operation done with difference pressure from well towards the perforated formation, which cause moving suspension (fines of jets or bullets) into perforators.
- 2- Acetic acid; this acid is the best perforating fluid under most conditions. Inhibitor corrosion add to acetic acid to prevent corrosion of metal when connect with the acid for long period and at high temperature, in case of absence of H₂S gas.
- 3- Nitrogen gas; in case of perforation low pressure formation, or rig time and swabbing cost is very expense, it better used Nitrogen gas in perforation operations.

Selection of Perforated Intervals

The perforated interval in production zone selected based on result all or most the following factors:

- 1- Electric, sonic, and radioactive logs show the border of oil and water formation.
- 2- Result of drill stem tests that conduct during well drilling.
- 3- Cores that extract from producing formation.
- 4- Geologic formations.

Take in account the following factors when select the perforating intervals;

- 1- The bottom perforated should far from Oil Water Contact (OWC) to avoid water coning.
- 2- The top perforated should far from Gas Oil Contact (GOC) to avoid gas coning.
- 3- Select zones with high porosity and permeability and avoid shale zones.
- 4- Select interval perforation that complete perforated with minimum numbers of guns run (the gun length is 10 meters), to minimize the cost and provide the safety.
- 5- The well should fill with a fluid does not cause any formation damage.

Water and Gas Coning

Coning is a term used to describe the mechanism underlying the upward movement of water and/or the down movement of gas into the perforations of a producing well or the open hole interval. Coning can seriously impact the well productivity and influence the degree of depletion and the overall recovery efficiency of the oil reservoirs. The specific problems of water and gas coning are listed below.

- 1- Costly added water and gas handling.
- 2- Reduced efficiency of the depletion mechanism.
- 3- The water is often corrosive and its disposal costly.
- 4- Loss of the total field overall recovery.

Delaying the encroachment and production of gas and water are essentially the controlling factors in maximizing the field's ultimate oil recovery.

The coning is primarily the result of movement of reservoir fluids in the direction of least resistance, balanced by a tendency of the fluids to maintain gravity equilibrium. The analysis may be made with respect to either gas or water. Let the original condition of reservoir fluids exist as shown schematically in figure - 43, water underlying oil and gas overlying oil.




Figure - 43: Original reservoir static condition

Production from the well would create pressure gradients that tend to lower the gas-oil contact and elevate the water-oil contact in the immediate vicinity of the well. Counterbalancing these flow gradients is the tendency of the gas to remain above the oil zone because of its lower density and of the water to remain below the oil zone because of its higher density. These counterbalancing forces tend to deform the gas-oil and water-oil contacts into a bell or cone shape as shown schematically in figure - 44.




Figure - 44: Gas and Water coning

There are essentially three forces that may affect fluid flow distributions around the well-bores. These are:

- 1- Capillary forces.
- 2- Gravity forces.
- 3- Viscous forces.

Capillary forces usually have negligible effect on coning and will be neglected. Gravity forces are directed in the vertical direction and arise from fluid density difference.

Viscous forces refer to the pressure gradients associated fluid flow through the reservoir as described by Darcy's law. Therefore, at any given time, there is a balance between gravitational and viscous forces at points on and away from the well completion interval. When the dynamic (viscous) forces at the well-bore exceed gravitational forces, a "cone" will ultimately break into the well.

We can expand on the above basic visualization of coning by introducing the concept of:

- Stable cone.
- Unstable cone
- Critical production rate.

If a well is produced at a constant rate and the pressure gradients in the drainage system have become constant, a steady-state condition is reached. If at this condition the dynamic forces at the well are less than the gravity forces, then the water or gas cone that has formed will not extend to the well. Moreover, the cone will neither advance nor recede, thus establishing what is known as a stable cone. Conversely, if the pressure in the system is an unsteady-state condition, then an unstable cone will continue to advance until steady-state conditions prevail.

The critical production rate is the rate above which the flowing pressure gradient at the well causes water (or gas) to cone into the well. It is, therefore, the maximum rate of oil production without concurrent production of the displacing phase by coning. At the critical rate, the built-up cone is stable but is at a position of incipient breakthrough.

Defining the conditions for achieving the maximum water-free and/or gas-free oil production rate is a difficult problem to solve. Engineers are frequently faced with the following specific problems:

- 1- Predicting the maximum flow rate that can be assigned to a completed well without the simultaneous production of water and/or free-gas.
- 2- Defining the optimum length and position of the interval to be perforated in a well in order to obtain the maximum water and gas-free production rate.

Critical rate Q_{oc} is defined as the maximum allowable oil flow rate that can be imposed on the well to avoid a cone breakthrough. The critical rate would correspond to the development of a stable cone to an elevation just below the bottom of the perforated interval in an oil-water system or to an elevation just above the top of the perforated interval in a gas-oil system.

There are several empirical correlations that are commonly used to predict the oil critical rate, including the correlations of:

- 1- Meyer and Gardner and Pirson Methods.
- 2- Craft and Hawkins Method.
- 3- Chaney Et AL. Method

1- Meyer and Gardner and Pirson Methods

Meyer, Gardner, and Pirson suggest that coning development is a result of the radial flow of the oil and associated pressure sink around the well-bore. In their derivations, Meyer, Gardner, and Pirson assume a homogeneous system with a uniform permeability throughout the reservoir, i.e., $k_h = k_v$. It should be pointed out that the ratio k_h/k_v is the most critical term in evaluating and solving the coning problem. They developed three separate correlations for determining the critical oil flow rate:

- Gas coning
- Water coning
- Combined gas and water coning.

Gas coning

Consider the schematic illustration of the gas-coning problem shown in figure - 45. Meyer, Gardner, and Pirson correlated the critical oil rate required to achieve a stable gas cone with the following well penetration and fluid parameters:

- Difference in the oil and gas density.
- Depth D_f from the original gas-oil contact to the top of the perforations.
- The oil column thickness h .

The well perforated interval h , in a gas-oil system, is essentially defined as:

$$h = h_p - D_f$$




Figure - 45: Gas coning

Meyer, Gardner, and Pirson propose the following expression for determining the oil critical flow rate in a gas-oil system:

Summary of assumptions for gas-oil system:

1. Capillary forces usually have negligible effect on coning and will be neglected.
2. No gas drive, that means GOR remain constant

= Potential = H

For any point, calculate H

$$\Phi = g + \frac{P - P}{\rho} \dots \dots \dots (1)$$

$$\Phi = H * g \rightarrow H = \frac{\Phi}{g}$$

$$H_{gas} = z + P_g / (g_{gas}) \dots \dots \dots (2)$$

$$H_{oil} = z + P_o / (g_{oil}) \dots \dots \dots (3)$$

Since $P_c = \text{zero}$ i.e., $P_o = P_g$ (where $P_c = P_g - P_o = \text{zero}$)

& $H_g = \text{constant}$ (i.e., no gas drive).

For eg.(2) , solving for P_g

$$(H_g - z) * g_{gas} = P_g \dots \dots \dots (2-a)$$

& also eq.(3) becomes:-

$$(H_o - z) \rho_o g = P_o \dots\dots\dots(3-a)$$

Since $P_c = \text{zero}$ $P_o = P_g$

Then eq. (2-a) = eq. (3-a)

$$(H_g - z) \rho_g g = (H_o - z) \rho_o g \dots\dots\dots(4)$$

Solve eq. (4) for H_o

$$H_o = H_g \left(\frac{\rho_g}{\rho_o} \right) + z \left[\left(\frac{\rho_o - \rho_g}{\rho_o} \right) \right] \dots\dots\dots (5)$$

Where H_g is constant

Derivative equation (5) respect to H_o

$$dH_o = \left[\left(\frac{\rho_o - \rho_g}{\rho_o} \right) dz \right] \dots\dots\dots(6)$$

Darcy's law $Q = k A \frac{P}{\mu L}$ (for linear flow)'

Solving for oil flow:


$$Q = Q_o$$

$$k = k_o$$

$$L = dr$$

$$\mu = \mu_o$$

$$\text{Radial area } A = 2 \pi r z$$



$$P = \rho_o g dH_o$$

Where $P = \rho_o g H$

Then Darcy's law

$$Q_o = 2 \pi \rho_o g (k_o/\mu_o) z r (dH_o/dr) \dots\dots\dots (7)$$

Substitute the value of (dH_o) [i.e. eq.(6) in eq.(7)]

For radial flow

$$Q_o = 2 \pi \left(\frac{\rho_o - \rho_g}{\rho_o} \right) g (k_o/\mu_o) z r (dz/dr) \dots\dots\dots (8)$$

$$Q_m = \int_r^r \frac{d}{r} = 2 (\rho_o - \rho_g) g \left(\frac{K}{\mu} \right) z r \int_{(h-D)}^h z d$$

$$Q_m = \pi g \left[\frac{\rho_o - \rho_g}{l_i \left(\frac{r}{r} \right)} \right] * \left(\frac{K}{\mu} \right) [h^2 - (h - D)^2] \dots \dots \dots (1)$$

Or in field units

$$Q_m = 0.0 \dots \dots \dots * \left[\frac{\rho_o - \rho_g}{l_i \left(\frac{r}{r} \right)} \right] * \left(\frac{K}{\mu B} \right) [h^2 - (h - D)^2] \dots \dots \dots (1)$$

Q_{o max} = maximum oil production rate without gas coning (critical rate), STB/day

- ρ_o = oil density, gram/ cm³
- ρ_g = gas density, gram/ cm³
- r_e = drainage area radius, ft
- r_w = well-bore radius, ft
- k_o = oil permeability, md
- μ_o = oil viscosity, cp
- B_o = oil formation volume factor, bbl/STTB
- h = thickness of oil zone (producing zone), ft
- D_t = Depth from the original gas-oil contact to the top of the perforations, ft
- h_p = Completion interval (Perforated interval), ft.

Example (1-1):

A vertical well is drilled in an oil reservoir overlaid by a gas cap. The related well and reservoir data are given below:

Horizontal and vertical permeability, i.e., k_h = k_v = 110 md

Oil relative permeability, k_{ro} = 0.85

Oil density, ρ_o = 47.5 lb/ft³

Gas density, ρ_g = 5.1 lb/ft³

Oil viscosity, μ_o = 0.73 cp

Oil formation volume factor, B_o = 1.1 bbl/day

Oil column thickness, h = 40 ft

Perforated interval, h_p = 15 ft

Depth from GOC to top of perforations, D_t = 25 ft

Well-bore radius, $r_w = 0.5$ ft

Drainage radius, $r_e = 660$ ft

Using Meyer, Gardner, and Pirson relationships, calculate the critical oil flow rate.

Solution

The critical oil flow rate for this gas-coning problem can be determined by applying equation (11). The following two steps summarize Meyer, Gardner, and Pirson methodology.

Step 1. calculate effective oil permeability, k_o

$$k_o = k_{ro} k = 0.85 * 110 = 93.5 \text{ md}$$

Step 2. solve for Q_{oc} by applying equation (11)

$$Q_{oc} = Q_{o \text{ max}} = 0.001535 [((47.5/62.4) - (5.1/62.4)) / \ln(660/0.25)] (93.5/0.73 * 1.1) [40^2 - (40 - 25)^2]$$

$$Q_{oc} = Q_{o \text{ max}} = 21.20 \text{ STB/day}$$

Water Coning

Meyer, Gardner, and Pirson proposed a similar expression for determining the critical oil rate in the water coning system shown schematically in figure - 46.

The proposed relationship has the following form:

$$Q_{m \text{ cr}} = 0.0 * \left[\frac{\rho_o - \rho_w}{l_1 \left(\frac{r}{r} \right)} \right] \left(\frac{K}{\mu B} \right) [h^2 - (h - h_w)^2] \dots \dots \dots (1)$$




Figure - 46: Water coning

Where:

w = water density, gram/ cm^3

D_b = Depth from the original water-oil contact to the bottom of the perforations, ft

Example (1-2):

Resolve example (1-1) assuming that the oil zone is underlaid by bottom water. The water density is given as 63.76 lb/ft. the well completion interval is 15 ft as measured from the top of the formation (no gas cap) to the bottom of the perforations.

Solution:

The critical oil flow rate for this water-coning problem can be estimated by applying equation (12). The equation is designed to determine the critical rate at which the water cone “touches” the bottom of the well to give.

$$Q_o \text{ max} = 0.001535 [((63.76/62.4)-(47.5/62.4))/ \ln(660/0.25)] (93.5/0.73*1.1) \quad [40^2 - 15^2]$$

$$Q_o \text{ max} = 8.13 \text{ STB/day}$$

Simultaneous Gas and Water coning

If the effective oil-pay thickness h is comprised between a gas cap and a water zone figure - 47, the completion interval h_p must be such as to permit maximum oil-production rate without having gas and water simultaneously produced by coning, gas breaking through at the top of the interval and water at the bottom.

This case is of particular interest in the production from a thin column underlaid by bottom water and overlaid by gas.]




Figure - 47: The development of Gas and Water coning

For this combined gas and water coning, Pirson (1977) combined equation (11) and (12) to produce the following simplified expression for determining the maximum oil-flow rate without gas and water coning:

$$Q_{omax} = Q_{ow} + Q_{og} \dots (13)$$

$$Q = 0.0 \left(\frac{K}{\mu_o B} \right) \left[\frac{(h^2 - hp^2)}{h \frac{r}{r}} \right] \left[\frac{(\rho_w - \rho_o)(\rho_o - \rho_g)}{\rho_w - \rho_g} \right]^2 + (\rho - \rho) \left(1 - \left[\frac{\rho - \rho}{\rho - \rho} \right]^2 \right) \dots \dots \dots (1)$$

Example (1-3):

A vertical well is drilled in an oil reservoir that is overlaid by a gas cap and underlaid by bottom water. Figure - 48 shows an illustration of the simultaneous gas and water coning.




Figure – 48: Gas and Water coning problem (example, 1-3)

The following data are available:

Horizontal and vertical permeability, i.e., $k_h = k_v = 110$ md

Oil relative permeability, $k_{ro} = 0.85$

Oil effective permeability, $k_o = 93.5$ md

Oil density, $\rho_o = 47.5$ lb/ft³

Water density, $\rho_w = 63.76$ lb/ft³

Gas density, $\rho_g = 5.1$ lb/ft³

Oil viscosity, $\mu_o = 0.73$ cp

Oil formation volume factor, FVF, $B_o = 1.1$ bbl/STB

Oil column thickness, $h = 65$ ft

Perforated interval, $h_p = 15$ ft

Depth from GOC to top of perforations, $D_t = 25$ ft

Well-bore radius, $r_w = 0.5$ ft

Drainage radius, $r_e = 660$ ft

Calculate the maximum permissible oil rate that can be imposed to avoid cones breakthrough, i.e., water and gas coning.

Solution:

Apply equation (14) to solve for the simultaneous gas-and water coning problem, to give:

$$Q_{\text{omax}} = 0.001535(93.5/0.73*1.1)[(65^2-15^2)/(\ln(660/0.25))] \\ [(((63.76/62.4)-(47.5/62.4))(((47.5/62.4)-(5.1/62.4))/((63.76/62.4)-(5.1/62.4)))^2+((47.5/62.4)- \\ (5.1/62.4))(1-(((47.5/62.4)-(5.1/62.4))/((63.76/62.4)-(5.1/62.4))))^2]$$

$$Q_{\text{omax}} = 17.1 \text{ STB/day}$$

Pirson derives a relationship for determining the optimum placement of the desired h_p feet of perforation in an oil zone with a gas cap above and a water zone below. Pirson proposes that the optimum distance D_t from the GOC to the top of the perforations can be determined from the following expressed:

$$D_t = (h - h_p) \left[1 - \left(\frac{\rho - \rho}{\rho - \rho} \right) \right] \dots (15)$$

Where the distance D_t is expressed in feet.

Example (1-4):

Using the data given in example (1-3), calculate the optimum distance for the placement of the 15 foot perforations.

Solution:

Applying equation (15) gives:

$$D_t = (65 - 15) \left[1 - \frac{47.5 - 5.1}{63.76 - 5.1} \right] = 13.9 \text{ ft}$$

There are other methods in water and gas coning calculation like:

- **Craft & Hawkins Method**
- **Chaney Et AL. Method**

Completion Efficiency

Generally, there are difference types of well completions; the cased-hole completion has advantage characterize the open-hole completion by:

- 1- Excessive gas or water production can be controlled more easily.
- 2- Can be selectively stimulated.
- 3- Adaptable to multiple completion techniques.

The advantage of cased-hole completion comes in account of loss in well potential to produce with maximum rate because of casing and perforation. Also it is not unusual during drilling, completion, or work-over operations for materials such as mud filtrate, cement slurry, or clay particles to enter the formation and reduce the permeability around the well-bore which cause potential loss. This effect is commonly referred to as “well-bore damage” and the region of altered permeability is called the “skin zone” this zone can extend from a few inches to several feet from the well-bore as shown in figure - 49, it express by positive skin factor ($s = +$). Many other wells are stimulated by acidizing or fracturing, which in effect increases the permeability near the well-bore, expressed by negative skin factor ($s = -$). Figure - 50 shows pressure profile through porous media.




Figure – 49: near well bore skin effect.




Figure – 50: pressure profile, representative of positive and negative skin effects.

According to the above factors that cause pressure loss, there are many skin factors as following:

$$S_t = S_{fm} + S_c + S_{pp}$$

Where;

S_{fm} = Formation skin factor due to alteration formation characteristics (permeability).

Many wells either have a zone of reduced permeability near the well-bore resulting from drilling or completion operations or have been stimulated by acidizing or hydraulic fracturing.

Those factors that cause damage to the formation can produce additional localized pressure drop during flow. This additional pressure drop is referred to as p_{skin} . On the other hand, well stimulation techniques will normally enhance the properties of the formation and increase the permeability around the well-bore, so that a decrease in pressure drop is observed. The resulting effect of altering the permeability around the well-bore is called the skin effect.


Figure (2) compares the difference in the skin zone pressure drop for three possible outcomes:

- First outcomes: $p_{skin} > 0$, indicates an additional pressure drop due to well-bore damage, i.e., $k_{skin} < k$ and $s = +$.

- Second outcomes: $p_{skin} < 0$, indicates less pressure drop due to well-bore improvement, i.e., $k_{skin} < k$ and $s = -$.
- Third outcomes: $p_{skin} = 0$, indicates no changes in the well-bore condition, i.e., $k_{skin} = k$ and $s = 0$.

Hawkins (1956), suggested that the permeability in the skin zone, i.e., k_{skin} , is uniform and the pressure drop across the zone can be approximated by **Darcy's** equation. **Hawkins** proposed the following approach as shown in below figure:

$$p_{skin} = [p \text{ in skin zone due to } k_{skin} - p \text{ in skin zone due to } k]$$



$$P_s = (P_2 - P_1) = (P_3 - P_2) - (P_3 - P_1) \dots \dots \dots (1)$$

$$P_s = (P_1 - P_2) \dots \dots \dots (2)$$

Where:

$2 =$ pressure drop in the altered zone around the well bore (r_s, k_{skin}).

$1 =$ pressure drop in the undamaged zone (r_s, k).

Apply **Darcy's law** for radial-steady state flow with field units.

$$Q = 7.08 \cdot 10^{-3} \frac{k h (P - P)}{\mu_o B \ln(r/r)}$$

p_{ws} = static bottom hole (well bore) pressure, psi.
 p_{wf} = flowing bottom hole (well bore) pressure, psi.

$$p_{wf} = 141.2 \frac{Q_o \mu_o B_o \ln(r_s/r_w)}{kh} \dots\dots\dots(3)$$

$$p_{wf} = 141.2 \frac{Q_o \mu_o B_o \ln(r_s/r_w)}{k_{skin}h} \dots\dots\dots(4)$$

Substitute Eq. (3) & (4) in Eq. (2)

$$p_{skin} = 141.2 \frac{Q_o \mu_o B_o \ln(r_s/r_w)}{k_{skin}h} - 141.2 \frac{Q_o \mu_o B_o \ln(r_s/r_w)}{kh}$$

$$p_{skin} = 141.2 \frac{Q_o \mu_o B_o}{kh} \left[\frac{(k - k_{skin})}{k_{skin}} \ln\left(\frac{r_s}{r_w}\right) \right] \dots\dots\dots(5)$$

Van Everdingen defined S_{skin} as:-

$$(S_{skin})_{fm} = 141.2 \frac{Q_o \mu_o B_o}{kh} (S_{fm}) \dots\dots\dots(6)$$

Solving for S_{fm} equalizing Eqs. (5) & (6).

$$S_{fm} = \left[\frac{(k - k_{skin})}{k_{skin}} \ln\left(\frac{r_s}{r_w}\right) \right] \dots\dots\dots(7)$$

Re-exam Eq. (7)

Case-1 $k = k_a$ No damage, No stimulation
 $S_{fm} = 0$, $S_{skin} = 0$

Case-2 $k < k_a$ Damage
 $S_{fm} = +ve$, $S_{skin} = +ve$ increase total pressure drop
when produce with constant rate.

Case-3 $k > k_a$ Stimulation
 $S_{fm} = -ve$, $S_{skin} = -ve$ decrease total pressure drop
when produce with constant rate.

S_{pp} = skin factor due to partial penetration of the formation.

The skin factor S_{pp} , is affected by perforations in only a portion of the total formation thickness (effect of incompletely perforated interval). This factor causes an additional pressure drop near the well. The purpose from partial penetration of the formation is avoided water and gas coning.

S_{pp} is depended on penetration ratio ($b = h_p / h_t$) and (h_p / r_w). Where, h_t is the total formation thickness, h_p is height of the perforated interval, and r_w is well-bore radius. As shown in figure - 51




Figure – 51: partial penetration of formation by a well.

S_{pp} value is determined by figure – 52:by use value of b and (h_p / r_w).

S_{pp} is always +ve.

Also:
$$(s_{skin})_{pp} = 141.2 \frac{Q_o \mu_o B_o (S_{pp})}{Kh}$$

S_c = skin factor due to completion configuration.

Skin factor due to completion configuration is determined by use figure (1-41), (1-42), and figure (1-43), and the following data.

- 1- Perforating techniques (Bullet guns, Jet guns, Hydraulic perforator), and formation compressive strength. Used to determine formation penetration (distance of bullet penetrate the formation).
- 2- Perforation phase.
- 3- Area of perforated interval.
- 4- Perforation density, (number of perforation per foot of perforated interval).

$(S_c)_{chart}$ is corrected according to perforated zone, by: .

$$(S_c)_{cor} = (S_c)_{chart} (h_t / h_p)$$

Also:

$$(s_{skin})_c = 141.2 \frac{Q_o \mu_o B_o (S_c)_{cor}}{kh}$$

or

$$(s_{skin})_c = 141.2 \frac{Q_o \mu_o B_o (S_c)_{chart}}{kh}$$

$$\begin{aligned}
 & \text{So: } S_t = S_{fm} + S_c + S_{pp} \\
 (\text{skin})_{\text{total}} &= (\text{skin})_{S_{fm}} + (\text{skin})_{S_{pp}} + (\text{skin})_{S_c} \\
 (\text{skin})_{\text{total}} &= \frac{141.2 Q_o \mu_o B_o}{kh} (S_t)
 \end{aligned}$$







Figure - 52: skin factor due to partial penetration of the formation, S_{pp} .







Flow efficiency

$$F = \frac{I_{tP} - P_d \text{ which is } r_t \text{ tip } c_r \text{ f the w}}{A - P_d \text{ which is } r_t \text{ tip } s_r \text{ f sa w}}$$

$$\Delta(a) = \Delta(T) = \Delta(I_{tP}) + \Delta(s_r)$$

Or

$$(p_e - p_{wf})_{actual} = (p_e - p_{wf})_{total} = (p_e - p_{wf})_{ideal} + (p)_{skin}$$

Then

$$F = \frac{[(P_e - P_{wf})_{ideal} - (\Delta s_r) t_c]}{[(P_e - P_{wf})_{total}]}$$

- Ideal case (S_t = 0)

$$(Q)_{ideal} = 7.08 \cdot 10^{-3} \frac{k h (P_e - P_{wf})_{ideal}}{\mu_o B \ln(r_o/r_w)}$$

- Actual case

$$(Q)_a = 7.08 \cdot 10^{-3} \frac{k h (P_e - P_{wf})_a}{\mu_o B \ln(r_o/r_w)}$$

$$(Q)_a = 7.08 \cdot 10^{-3} \frac{k h [(P_e - P_{wf})_{ideal} + (p_{sk}) t_c]}{\mu_o B \ln(r_o/r_w)}$$

Or

$$(Q)_a = 7.08 \cdot 10^{-3} \frac{k h [(P_e - P_{wf})_{ideal}]}{\mu_o B [\ln(r_o/r_w) + S]}$$

FE > 1 Stimulation

FE < 1 Damage

p_e = Average reservoir pressure.

p_{wf} = Flowing bottom hole pressure.

Example;

From this data:

Oil column thickness = 25 ft, $k_o = 100$ md, $\mu_o = 0.5$ cp, Perforated zone thickness = 15 ft (from upper oil zone), Radius of drainage area = 660 ft, Total pressure drop = 1000 psi, well bore radius = (3/8) ft, B_o (oil formation volume factor) = 1.4 RB/STB, Perforating diameter = 2 inch, perforating (shots) density = 4 perforation(shots) / ft.

Jet guns used to perforation operation, and the bullet penetrate the casing and cement only (formation penetration = zero), and perforation phase in one side (all perforation in one side).

1- Ideal flow rate.

$$(Q_o)_{ideal} = 7.08 \cdot 10^{-3} kh (p_e - p_{wf}) / \mu_o B_o \ln(r_e/r_w)$$

$$(Q_o)_{ideal} = 7.08 \cdot 10^{-3} * 100 * 25 * 1000 / [0.5 * 1.4 * \ln(660/0.375)]$$

$$(Q_o)_{ideal} = 3383.5 \text{ STB/DAY.}$$

2- Actual flow rate.

$$(Q_o)_{actual} = 7.08 \cdot 10^{-3} kh (p_e - p_{wf}) / \mu_o B_o \{ \ln(r_e/r_w) + St \}$$

$$St = S_{fm} + (S_c)_{cor} + S_{pp}$$

$$S_{fm} = 0 \quad \text{no information}$$

$$S_{pp}$$

$$ht/r_w = 25/0.375 = 66.67$$

$$hp/ht = 15/25 = 0.6$$

$$\text{From figure (1-40) } S_{pp} = 1.7$$

$$(S_c)_{cor}$$

$$\text{From figure (1-42) } (S_c)_{chart} = 4.25$$

$$(S_c)_{cor} = (S_c)_{chart} (h_t / h_p)$$

$$(S_c)_{cor} = 4.25 * (25 / 15) = 6.88$$

So:

$$S_t = 0 + 6.88 + 1.7 = 8.58$$

$$(Q_o)_{actual} = 7.08 \cdot 10^{-3} * 100 * 25 * 1000 / 0.5 * 1.4 \mu_o B_o \{ \ln(660/0.375) + 8.58 \}$$

$$(Q_o)_{actual} = 1555.4 \text{ STB/DAY}$$

3- Pressure drop due to skin.

$$(\Delta p_{\text{skin}})_{\text{total}} = 141.2 \frac{Q_o \mu_o B_o}{kh} (S_t)$$

$$(\Delta p_{\text{skin}})_{\text{total}} = 141.2 \frac{1555.4 \times 0.5 \times 1.4}{100 \times 25} (8.58)$$

$$(\Delta p_{\text{skin}})_{\text{total}} = 528.74 \text{ psi}$$

$$FE = \frac{(p_e - p_{wf}) - (\Delta p_{\text{skin}})_{\text{total}}}{p_e - p_{wf}}$$

$$FE = \frac{1000 - 528.74}{1000}$$

$$FE = 0.47$$

Drill Stem Testing, DST

Drill Stem testing provides a method of temporarily completing a well to determine the productivity characteristics of a specific zone. As originally conceived, a Drill Stem Test provided primarily an indication of formation content. Also the pressure versus time chart was available.

Reservoir characteristics that may be estimated from DST analysis include;

- Average effective permeability
- Reservoir pressure
- Identify reservoir fluids
- Well-bore damage
- Barriers, fluid contacts
- Radius of investigation
- Depletion

Tools Used in DST

The type of DST tools depends on the testing well, whether it is cased or open hole.

a- Surface pressure control equipments

It is a collection of valves, flanges and nipples set on well head, used to control on flow rate and internal closed or flowing pressure.

b- Drill pipe

Drill pipe used as connection between surface equipment and test equipment.

c- Reverse circulation sub

This sub valve used to circulation the drill mud (reverses circulation, from annulus to inside drill pipe), for killing the well and control on well after the test was finish or in emergency cases, and the valve used to empty the drill test stem from fluids when pull out of hole. During the tools run in hole this valve remain closed and still closed until the test was finished, after that its open to control on well.

d- Drill collar

Used to set the packer and open or close tester valve by its weight.

e- Reverser circulation ports

Also, used to reverse circulation of drill mud after the test was complete.

f- Closed in pressure valve

The valve used to close the drill stem after the test was finish.

g- Flow choke

The flow choke with a specific diameter (5/8 inch) used to fluid flow through it and to calculations purpose.

h- Tester valve

This valve used to control on fluid movement (flow or close), the valve is closed by put the drill stem under tension, or open it by slack off the stem. (Some times the valve called multi flow evaluator MFE).

i- Upper pressure recorder

This instrument includes pressure record that consists from spiral tube that moves according to amount of supply pressure, the tube shifting is transit through a small needle to a black chart (previously, set on it lines with a specific pressure). All operations that occur during the test will recorded on the black chart as pressure versus time profile.

j- Hydraulic jar

It is a motional nipple, used to release the test stem in stuck case.

k- Safety joint

This joint is useful in case of stem stuck. When stem does not release, could back the part of stem by open it from the safety joint.

l- Packer

It is the important part of the test stem; consist from steel and rubber part. After set the packer by supply a certain weight, the rubber part will isolate the upper of well from the formation (remove the hydrostatic pressure from the formation). After the test on formation was completed, then the packer return to its normal situation by removes the supplied weight, and the formation will be under control by the hydrostatic mud column pressure.

m- Perforated pipe

Through this pipe the oil and gas enter inside the test stem.

n- Temperature recorder

This recorder used to record tested formation temperature.

o- Bottom pressure recorder

Its second pressure instrument also used to record flowing and closed bottom-hole pressure.

p- Tail pipe anchor

Tail pipe anchor is the last part of test stem used for support purpose.

Basics of DST operations

Simply a drill stem test is made by running in the hole on drill pipe a bottom assembly consisting of a packer and a surface operated valve. The DST valve (tester valve) is closed while the drill string is run, thus pressure inside the drill pipe is very low compared to hydrostatic mud column pressure (some times fill inside drill pipe with amount of water, called water cushion to reduce the impact of high pressure). Once on bottom, the packer is set to isolate the desired formation zone from mud column, and the control valve is opened to allow formation fluids to enter the drill pipe. After suitable period, the valve is closed, and a pressure build-up occurs below the valve as formation fluids repressure the area around the well-bore. After a suitable build-up time, the control valve usually is opened again, and the flowing and shut-in periods repeated, (several times if desired), to obtain additional data and verification. Figure – 54 shows schematically a simple single-flow period operational sequence.




Figure – 54: Fluid passage diagram, open-hole drill stem test.

Pressure versus Time Plot

The entire sequence of events is recorded on a pressure vs time plot shown schematically in figure - 55. As the tools are run in the hole, the pressure records the increase in hydrostatic mud column pressure. The pressure at point A is termed the initial hydrostatic mud pressure.

Initial Flowing and Shut-in Periods- one objective of the DST is to determine the static or shut—in reservoir pressure of the zone. To measure true static reservoir pressure, any over-pressured condition near the well-bore, due to drilling fluid filtration or fluid compression in setting the DST packer, must first be relieved by a short flowing period.

The control valve is then closed and pressure builds-up toward static reservoir pressure. Depending on the length of the flowing period, the length of the shut-in period, and certain reservoir parameters, the pressure may or may not level out at the true static reservoir pressure. Thus point B, initial shut-in pressure, may be somewhat less than true static reservoir pressure.

Second Flowing and Shut-in Periods- the objective of the second flowing and shut-in periods is to permit the calculation of reservoir parameters, as well as to determine fluid production. As the control valve is opened, pressure falls to point C (initial flowing pressure). As fluids move into the drill pipe above the recorder, pressure increases, reflecting the increase in hydrostatic head of liquid and in back pressure, due to flow restrictions in the tools.

After a suitable period of time, depending on test objectives, hole conditions and the cost of rig time, the tool is shut-in. The pressure at the moment of shut-in, point D, is termed the final flowing pressure. Recorded pressure then rises toward point E, the final shut-in pressure. Usually the final shut-in pressure is significantly less than the static reservoir pressure, again due to limitation of time relative to reservoir parameters.

This second pressure build-up portion of the DST, following a reasonably long flowing period, usually provides data for transient pressure analysis. Some-times DST's are designed having two reasonably long flowing period and subsequent shut-in periods, to provide verification of calculations, and to permit more sophisticated well testing techniques. Figure – 56 is typical of actual multiple-flow-period charts with key points described therein.





Figure - 55: Sequence of events in a DST



- | | | | |
|-----|---|-----|---|
| A-Q | Baseline drawn by recorder. | H | Final closed-in pressure of 1st period. |
| A | Recorder clock started. | I | Begin 2nd flow period (initial flow pressure). |
| A-B | Tools being made up. | J | End 2nd flow period (final flow pressure). |
| B-C | Running in hole. | K | End 2nd shut-in period (final closed-in) |
| C-D | On bottom—completing surface hookup—initial hydrostatic mud pressure. | K-L | Equalizing hydrostatic pressure across packer. |
| D | Tester valve opens. | M-N | Pulling out of hole. |
| E | Beginning 1st flow period (initial flow pressure). | N-O | Reached top of fluid fillup in drill pipe—reversing out fluid to surface. |
| E-F | Fluid filling small ID drill collars. | O-P | Continued trip out of hole. |
| F-G | Fluid filling larger ID drill pipe. | P-Q | Breaking down tools. |
| G | End 1st flow period (final flow pressure). | R-S | 1,000-psi lines drawn by |
| G-H | First closed-in pressure period. | T-U | chart interpreter. |

Figure -56: Typical chart for multiple-flow period DST

Theory of Pressure Build-up Analysis

Horner equation- transient pressure analysis of a DST is based on the Horner pressure build-up equation. This equation describes the repressuring of the well-bore area during the shut-in period, as formation fluid moves into the “pressure drop” created by the following portion of the DST, Horner equation is the one of solutions of diffusivity equation for fluid flow in porous media:

$$\frac{\partial^2 P}{\partial r^2} + \frac{1}{r} \cdot \frac{\partial}{\partial r} = \frac{\mu}{0.0002637 K h} \cdot \frac{\partial}{\partial t} \dots\dots\dots \text{(Diffusivity Equation) } \dots\dots\dots (2-1)$$

$$p_{ws} = p_i - 162.6 \frac{q \mu B}{K h} \log \left(\frac{t_p + t}{t} \right) \dots\dots\dots (H) \dots\dots\dots (2 - 2)$$

$$p_{ws} = p_i + m \log \left(\frac{t_p + t}{t} \right)$$

$$m = 162.6 \frac{q \mu B}{K h} \dots\dots\dots (2 - 3)$$

Comparing Eq.(2-3) with the equation of a straight line,
 $y = m x + b$

- y ~ p_{ws}
- b ~ p_i
- m ~ 162.6 $\frac{q_o B_o \mu_o}{k_o h}$
- x ~ log $\left(\frac{t_p + t}{t} \right)$

$$y = a + mx$$

- p_{ws} = shut in pressure (bottom hole pressure) measured in the well-bore during build up, psi
- p_i = static or initial shut-in reservoir pressure, psi
- k_o = oil permeability, md
- B_o = formation volume factor, RB/STB
- q_o = oil production rate, STB/day
- t = shut in time, hr
- t_p = flowing time, hr
- μ_o = oil viscosity, cp
- h = production zone thickness, ft
- c_t = reservoir fluid compressibility, dimensionless

Conditions which must be assumed during the build-up period for Horner equation to be strictly correct are:

- 1- Radial flow, steady state flow
- 2- infinite-acting reservoir
- 3- Homogenous & isotropic porous media
- 4- Single phase flow
- 5- Gravitational force is ignored

Assuming these conditions are met, then Horner build-up plot of p_{ws} versus $((t_p + t) / t)$ on semi-logarithmic paper should yield as shown in figure - 57:




Figure -57: Horner plot for pressure buildup test.

For ideal buildup pressure test, obtain a single straight line for all times, any well-bore damage or stimulation is considered to be concentrated in a skin of zero thickness at the well-bore; at the instant of shut-in, flow into the well-bore ceases totally.

For actual buildup test, obtain a curve with a complicated shape. To explain what went wrong, the radius of investigation concept is useful. Based on this concept, we logically can divide a buildup curve into three regions;

- I. An early-time region (ETR) during which a pressure transient is moving through the formation nearest the well-bore, (include well-bore effects well-bore storage, skin factor and non-Darcy effects).

- II. A middle-time region (MTR) during which the pressure transient has moved away from the well-bore and into the bulk formation. And the data are take from this region to estimate formation properties because its consider reservoir behavior.
- III. A late-time region (LTR), in which the radius of investigation has reached the well's drainage boundaries.

Steps of determining reservoir properties by using Horner plot to analysis pressure buildup

test:

- 1- Plot p_{ws} vs. $((t_p + t) / t)$ on semi-logarithmic paper, then delineate the straight line from **MTR** is called the correct semi-log straight line , the straight line slope (m) is found by simply subtracting the pressure at any two points on the straight line that are one cycle apart on the semi-log paper. Using absolute value of (m) to estimate effective formation permeability (k_o), by using this equation;

$$K = 162.6 \frac{q \mu B}{m h}$$

Where;

$$m = \frac{(p_{ws2} - p_{ws1})}{(\log(10) - \log(1))} = \frac{p}{c}$$

$$F C = K h = \frac{162.6 q \mu B}{m}$$

$$T = \frac{K h}{\mu B} = 162.6 \frac{q}{m}$$

- 2- From semi-log graph, the original reservoir pressure (p_i), is estimated by extrapolating the straight line to infinite shut-in time where $((t_p + t) / t) = 1$.
- 3- Also can determine skin factor, s from the data available, by use the following equation:

$$S = 1.151 \left[\frac{(p - P)}{m} - \log \left(\frac{K t_i}{\mu C r w^2} \right) + 3.23 \right] \dots \dots \dots (2 - 4)$$

Or

$$S = 1.151 \left[\frac{(p_{1hr} - P)}{m} - \log \left(\frac{K}{\mu C r w^2} \right) + 3.23 \right] \dots \dots \dots (2 - 5)$$

In summary, if we plot p_{ws} vs. $\log ((t_p - t) / t)$ with information obtained from a pressure buildup test, we can estimate effective permeability, k, original reservoir pressure, p_i , and the skin factor, S.

Radius of investigation (r_i)

It's a distance that a pressure transient has moved into a formation following a rate change in a well, this distance is related to formation rock and fluid properties and time elapsed since the rate change.

$$r_i = \left(\frac{K t}{9 \mu c} \right)^{0.5} \dots\dots\dots (2-6)$$

r_i = investigation radius, ft. k_o = permeability, md. t_p = flow time, hours. Ø = porosity.
 μ_o = viscosity, cp. c_t = total compressibility, psi⁻¹

Example:

- DST analysis, from this data
- Thickness of testing formation = 50 ft
- Section length of produce oil = 600 ft (steam testing)
- Steam testing consist of:
 - 1- Drill collar pipe length = 300 ft , capacity = 0.0061 bbl/ft
 - 2- Drill pipe capacity = 0.0142 bbl/ft
- Oil API = 35, reservoir temperature = 120 F
- t_{pi} = 5 minute, t_i = 30 minute, p_{ws_i} = 1910 psi
- t_{pf} = 60 minute, t_f = 45 minute, p_{wf} = 350 psi, p_{wsf} = 1765 psi

Data of p_{wsf} vs. t_f

<u>p_{wsf} (psi)</u>	<u>Δt_f (min)</u>
965	5
1215	10
1405	15
1590	20
1685	25

Determine the following:

- 1- p_i
- 2- q_o
- 3- k_o = ?, μ_o = 1.5 cp, B_o = 1.15 RB/STB, Net pay thickness = 10 ft

- 4- FE
- 5- $r_i = ?$, $\emptyset = 10\%$, $c_t = 8.4 \times 10^{-6} \text{ psi}^{-1}$

Solution

- 1- Plot $p_{ws}f$ vs. $((t_p + t)/t)$ on semi-log paper, draw the straight line from the transient region, extent the line to intercept it with $((t_p + t)/t) = 1$, to determine $p_i = 1910 \text{ psi}$.
- 2- Total produce oil rise in drilling pipe = 600 ft during 65 minute flowing time, then oil volume in drill collar pipe = $(300 \times 0.0061 = 1.83 \text{ bbl})$, oil volume in drill pipe = $(300 \times 0.0142 = 4.26 \text{ bbl})$, the total oil volume produce = $(1.83 + 4.26 = 6.09 \text{ bbl})$.
 $q_o = 6.09 \text{ bbl} / 65 \text{ min} \times 1440 \text{ min/day} = 135 \text{ bbl/day}$.


3- By slope of straight line, determine k_o
 $k_o = 162.6 \times 135 \times 1.5 \times 1.15 / 372 \times 10 = 10.2 \text{ md}$

4- Determine FE,
 $S = 1.151 [((1910 - 350)/372) - (\log(10.2 \times (65/60) / 0.1 \times 1.5 \times 8.4 \times 10^{-6} \times 0.333^2) + 3.23)]$
 $S = -0.55$

$$P_{skin} = 141.2 \times (135 \times 1.5 \times 1.15 / 10.2 \times 10) \times -0.55 = -323.4 \text{ psi}$$

$$FE = 1910 - 350 - (-323.4) / 1910 - 350 = 1.2$$

$$5- r_i = [10.2 \times 65 / 5.76 \times 10^4 \times 0.1 \times 1.5 \times 8.4 \times 10^{-6}]^{1/2} = 95.6 \text{ ft} \qquad P_i = 1910 \text{ psi}$$



Reservoir and fluid anomaly indications

Many times the assumption of the Horner build-up equation, homogeneous formation, single phase flow and infinite reservoir, do not hold in an actual case. If changes occur within the radius of investigation of the DST, they can be detected by a change in slope of the Horner build-up plot.

Permeability or Viscosity- Examining the Horner slope equation, it is seen that if rate of flow q remains constant, then permeability k , or fluid viscosity μ , are likely suspects for change as the wave of increasing pressure travels toward the well-bore.

Permeability may change due to natural lensing or due to formation damage, figure – 58 A. It is doubtful, however, that formation damage would affect sufficient volume of formation to be detected as a change of slope on the build-up plot. Fluid viscosity could change due to a change in fluid phase or type (i.e., gas to oil). “Seeing” the gas-liquid contact from the up-structure well of figure – 58 B, would be difficult, due to the normally short radius of investigation through a gas column. Seeing the gas-liquid contact from the down-structure well is a much more likely possibility.




Figure – 58: Effect of changing permeability and viscosity

Barrier- A sealing barrier such as a fault or permeability pinch-out can cause a change of m . if the barrier is a straight line as A-A` in figure – 59 A, then the build-up slope will change by a factor of 2, figure – 59 B.




Figure - 59 Effect of a fault

In summary, a change in permeability, or viscosity, or existing of a barrier, all can cause a change in the slope of the Horner plot. Thus, the fact that a change in slope appears on the build-up plot leaves open the question of what caused the anomaly. This must be resolved through other geologic or reservoir information.

Distance to anomaly (Fault)- The distance to the anomaly, (r_a) whether it be a barrier, or change of permeability, or a fluid contact, can be calculated using Horner's equation:

$$- Ei \left[\frac{-3}{K t_i} \frac{r_a^2 \phi \mu c}{t_i} \right] = 2.303 \ln \left(\frac{(t_p + t_a)}{t_a} \right) \dots \dots (2-7)$$

r_a = Distance to anomaly, ft

t_p = Flow time, hours

t_a = shut-in time at the point of slope change, hours

- E_i = Exponential integral value- See figure – 60.




Figure – 60: Exponential integral values

Depletion

If the extrapolated or stabilized shut-in pressure from the second build-up is lower than the initial shut-in pressure, a depleting reservoir may be the cause. Obviously a reservoir must be extremely small for depletion to occur on a DST, but many field examples are available to prove that it can occur.

Another possibility, however, is that the recorded initial shut-in pressure may be higher than true shut-in reservoir pressure. This effect is called supercharge. Supercharge could be due to leak off of drilling fluid filtrate over-pressuring the formation around the well-bore, or to compression of well fluid below the DST packer as it was set.

In some formations a short initial flowing period (1 to 3 minutes) is not sufficient to relieve the over-pressured condition. Where this condition is suspected to exist, longer initial flowing periods (perhaps 20 minutes) should be used.

The important point is that the question of supercharge must be resolved before depletion can be diagnosed. A second DST is sometimes required to define depletion.

Example; A new oil well produced 123 STB/Day for 97.6 hours; it then was shut-in for a pressure buildup test, during which the data in table (1) were recorded.

$t = 12$ hours, $p_{wf} = 4506$ psi.

Table (1) pressure buildup test data

<u>p_{ws} (psi)</u>	<u>Δt (hrs)</u>
4506	0
4675	0.5
4705	0.66
4733	1
4750	1.5
4757	2
4761	2.5
4763	3

Determine the following:

- 1- p_i
- 2- $k_o = ?$, $\mu_o = 1$ cp, $B_o = 1.22$ RB/STB, Net pay thickness = 20 ft
- 3- FE
- 4- $r_i = ?$, $\emptyset = 20\%$, $c_t = 20 \times 10^{-6}$ psi⁻¹, $r_w = 0.3$ ft.

Solution

1- Plot p_{ws} vs. $((t_p + t) / t)$ on semi-log paper, draw the straight line from the transient region MTR, extent the line to intercept it with $((t_p + t) / t) = 1$, to determine $p_i = 4800$ psi.


2- By slope of straight line, determine k_o
 $m = (4800 - 4775.5) / (\log 10 - \log 1) = 24.5$ psi / cycle.
 $k_o = 162.6 * 123 * 1 * 1.22 / 24.5 * 20 = 50$ md

3- Determine FE,
 $s = 1.151 [((4752 - 4506) / 24.5) - (\log(50 / 0.2 * 1 * 20 * 10^{-6} * 0.3^2) + 3.23)]$
 $s = 6$

$$P_{skin} = 141.2 * (123 * 1 * 1.22 / 50 * 20) * 6 = 128 \text{ psi}$$

$$FE = (P - P_{skin}) / P = (4800 - 4506 - (128)) / (4800 - 4506) = 0.56$$

$$4- r_i = [50 * 97.6 / 948 * 0.2 * 1 * 20 * 10^{-6}]^{1/2} = 1134 \text{ ft}$$



Oil and Gas Separation

Produced well-head fluids are complex mixtures of different compounds of hydrogen and carbon, all with different densities, vapor pressures, and other physical characteristics. As a well stream flows from the hot, high-pressure petroleum reservoir, it experiences pressure and temperature reductions. Gases evolve from the liquids and the well stream changes in character. The velocity of the gas carries liquids droplets, and the liquid carries gas bubbles. The physical separation of these phases is one of the basics operations in the production, processing, and treatment of oil and gas.

In oil and gas separator design, we mechanically separate from a hydrocarbon stream the liquid and gas components that exist at a specific temperature and pressure. Proper separator design is important because a separation vessel is normally the initial processing vessel in any facility, and improper design of this process component can “bottleneck” and reduce the capacity of the entire facility.

Separators are classified as “two-phase” if they separate gas from the total liquid stream and “three-phase” if they also separate the liquid stream into its crude oil and water components.

Separators are sometimes called “gas scrubbers” when the ratio of gas rate to liquid rate is very high. Some operators use the term “traps” to designate separators that handle flow directly from wells. In any case, they all have the same configuration and are sized in accordance with the same procedure.

Factors effecting separation

Characteristics of the flow stream will greatly affect the design and operation of a separator. The following factors must be determined before separator design;

- 1- Gas and liquid flow rates (minimum, average, and peak)
- 2- Operation and design pressures and temperatures.
- 3- Surging and slugging tendencies of the feed streams.
- 4- Physical properties of the fluids such as density and compressibility.
- 5- Designed degree of separation (e.g., removing 100% of particles greater than 10 microns).
- 6- Presence of impurities (paraffin, sand, scale, etc.).
- 7- Foaming tendencies of the crude oil.
- 8- Corrosive tendencies of the liquids or gas.

Vessel internals

Figure -61 is a schematic of a separator.

- 1- Inlet diverters (primary separation section); there are many types of inlet diverters. Two main types are baffle plates and centrifuge diverters (shown in figure - 62). A baffle plate can be a spherical dish, flat plate, angle iron, cone, or just about anything that will accomplish a rapid change in direction and velocity of the fluids and thus disengage the gas and liquid.
- 2- Mist extractor (secondary separation section); some of the drops are of such a small diameter that they are not easily separated in the gravity settling section, before the gas leaves the vessel it passes through mist extractor. This section uses elements of vanes, wire mesh, or plates (as shown in figure - 63) to coalesce and remove the very small droplets of liquid in one final separation before the gas leaves the vessel.
- 3- Gas out; by controlling the rate at which gas leaves the vapor space of the vessel the pressure in the vessel is maintained, the pressure in the separator is maintained by a pressure controller.
- 4- Collection section; the liquid collection section provides the retention time required to let entrained gas evolve out the oil and rise to the vapor space.
- 5- Liquid out; the liquid leaves the vessel through the liquid dump valve, where it is regulated by a level controller. The level controller senses changes in liquid level and controls the dump valve accordingly.




Figure – 61: separator schematic.




Figure – 62:baffle plates.




Figure – 63: mist extractor.

Separators types

Classification of separators according to configuration:

- a- Vertical separators
- b- Horizontal separation
 - 1- mono tube
 - 2- dual tube
- c- Spherical separators


Vertical separator

Figure - 64 is a schematic of a vertical separator. The advantages are;

- 1- Adequate for medium or low GOR fluids.
- 2- Easy to remove the impurities (paraffin, sand, scale, etc.) from inside the vessel.
- 3- Vertical vessel requires small plan area, it could be very important in offshore.
- 4- Relatively easy to deal with the effluent liquids waves.

M

Figure -64: schematic of a vertical separator.



Horizontal separator

Figure - 65 is a schematic of two types of horizontal separator. The advantages are;

- 1- Adequate for high GOR fluids and foaming oil.
- 2- Less expensive compare with the other types.

- 3- The interface area is larger in a horizontal vessel than the other types; it is easier for the gas bubbles, which come out of solution as the liquid approaches equilibrium, to reach the vapor space.
- 4- Easy to shipping and structure.




Figure – 65: schematic of a horizontal separator.

Spherical separator

Figure – 66 is a schematic of a spherical separator. The advantages are;

- 1- Use for low and homogenous production rate.
- 2- More cheap than Vertical and horizontal separators.
- 3- Easy to clean and drain.




Figure – 66: schematic of a spherical separator.

Classification of separators according to function:

- 1- Two phases separators.
- 2- Three phases separators.

Classification of separators according to operating pressure:

- 1- High pressure separators [1500 psi]
- 2- Medium pressure separators [650 psi]
- 3- Low pressure separators [60 psi]

Separators Design

The basic factors that effect on separators design are;

- 1- Working pressure.
- 2- Working temperature.
- 3- Fluid components.

Separator design consisting as follows;

- 1- Calculate gas section capacity.
- 2- Calculate oil section capacity.

Capacity of a vertical separator

1- Gas capacity

Suppose there is a liquid drop in the gravity settling section, the liquid drops will settle at a velocity determined by equating the gravity force (F_d), on the drop with the drag force (F_u) caused by its motion relative to the gas continuous phase.

$$\text{- Upward force } F_u = \left(\frac{1}{4} \right) d_p^2 k_g u^2 \dots(1)$$

$$\text{- Downward force } F_d = \left(\frac{1}{6} \right) d_p^3 (\rho_o - \rho_g) g \dots(2)$$

d_p = droplet diameter

k = empirical constant

ρ_g = gas density lb/ft³

ρ_o = oil density lb/ft³

u = gas velocity

g = acceleration due to gravity

If $F_u = F_d$

Then the droplet will remain suspended and gas velocity call suspending velocity.

$$\left(\frac{1}{4} \right) d_p^2 k_g u^2 = \left(\frac{1}{6} \right) d_p^3 (\rho_o - \rho_g) g \dots(3)$$

$$u = [2g d_p (\rho_o - \rho_g) / (3k \rho_g)]^{0.5} \dots(4)$$

If $u = d_p$ & k remain constant then

$$u = c [(\rho_o - \rho_g) / \rho_g]^{0.5} \dots(5)$$

u = suspending velocity

$$c = [2g/3k]^{0.5} = \text{separate constant}$$

$$q_g = (\pi / 4) d^2 u \dots (6)$$

d = inside diameter of separator

$$q_g = (\pi / 4) d^2 c [(\rho_o - \rho_g) / \rho_g]^{0.5} \dots(7)$$

q_g = gas flow rate at separator condition Scf/sec

Apply mass balance equation on gas under separator condition and standard condition:

$$q_g \rho_g = q_{gsc} \rho_{gsc} \dots(8)$$

q_{gsc} = gas flow rate at standard condition Scf/sec

ρ_{gsc} = gas density at standard condition lb/ft³

$$\rho_g = p M_w / zRT \dots (9)$$

$$\rho_g = M_w \text{ gas} / M_w \text{ air} = M_w \text{ gas} / 29$$

$$\rho_{gsc} = p_{sc} M_w / RT_{sc} \dots (10)$$

M_w = Molecular weight

z = Gas deviation factor (compressibility factor)

R = Gas constant

T = Temperature

ρ_g = Gas specific gravity

Substitute eq. (7),(9) & (10) in eq. (8)

$$q_{gsc} = (\pi / 4) d^2 c [(\rho_o - \rho_g) / \rho_g]^{0.5} (p M_w / zRT) / (p_{sc} M_w / RT_{sc})$$

In field units:

$$q_{gsc} = 67824 * 10^{-6} d^2 c [(\rho_o - \rho_g) / \rho_g]^{0.5} (p T_{sc} / zT p_{sc}) \dots(11)$$

q_{gsc} = gas flow rate at standard condition, MMScf/day

d = inside diameter of separator, ft

p = separator operating pressure, psia

p_{sc} = standard pressure = 14.7 psia

T = separator operating temperature, °R

T_{sc} = standard temperature = 520 °R, (°R = °F + 460)

$$q_{gsc} = 2.4 d^2 c [(\rho_o - \rho_g) / \rho_g]^{0.5} (p / zT) \dots(11)$$

2- Oil capacity

Oil capacity design depended on retention time; therefore this time should be enough to give solution gas in oil the chance to be freely.

For most application retention times of between 30 seconds and 3 minutes have been found to be sufficient. Where foaming crude is present retention times up to four times this amount may be needed.

$$V_o = (\pi/4) d^2 h_o \dots(12)$$

V_o = volume of oil section, ft³

d = inside diameter of separator, ft

h_o = height of oil section, ft

$$q_{o \text{ actual}} = V_o / t$$

$$q_{o \text{ actual}} = (\pi/4) d^2 h_o / t (1/5.615) (1440)$$

$$q_{o \text{ actual}} = 201.4 d^2 h_o / t \dots(13)$$

$$q_{or} = 1/2 q_{o \text{ actual}}$$

$$q_{or} = 100.7 d^2 h_o / t \dots(14)$$

$q_{o \text{ actual}}$ = actual oil capacity bbl/day

q_{or} = rated oil capacity under separator condition bbl/day

t = retention time, minute

From oil capacity and gas capacity calculations can determine inside diameter of separator, height of gas section (gas section volume), height of oil section (oil section volume), and then separator volume (gas section volume + oil section volume).

The volume (size, d) of a vertical separator can be estimated approximately (ignore temperature, gas density and some factors effects), if the following data are known:

- 1- Operating pressure
 - 2- Oil gravity (API)
 - 3- Gas capacity (daily gas production MMcf/day)
- and by figure (4-7), determine (d).

Capacity of a vertical separator = $9.7 * 10^{-4} d^2$, d in inch

Generally height of gas section, $h_g = 2 d$

Estimating height of oil section, h_o

Volume of oil section, $V_o =$ oil production rate, $q_o * \text{retention time, } t$

Height of oil section, h_o (ft) = V_o , bbl / separator capacity, bbl/ft

Height of a vertical separation, $L = h_o + h_g$

Example (1):

Calculate the Gas & Oil capacity for vertical separator, use the following data:

$L = 10$ ft, $h_o = 3.25$ ft, $d = 24$ in, $\gamma_g = 0.8$, $API = 45^\circ$, $p = 400$ psi,

$T = 60^\circ\text{F}$, $c = 0.167$, $z = 1$, $t = 1$ minute.

Solution:

1- Apply eq.(11) to determine gas capacity:

$$q_{gsc} = 67824 * 10^{-6} d^2 c [(\gamma_o - \gamma_g) / \gamma_g]^{0.5} (p T_{sc} / z T p_{sc}) \dots(11)$$

$$API = (141.5 / \gamma_o) - 131.5$$

Oil specific gravity, $\gamma_o = 0.8017$ $\gamma_o = \rho_o / \rho_{\text{water}}$

Oil density, $\rho_o = 62.4 * 0.8017 = 50.02$ lb/ft³.

$$\rho_g = p M_{w_{\text{gas}}} / zRT = p (M_{w_{\text{air}}} \gamma_g) / zRT = 400 (0.8 * 29) / 1 * 10.73 * 520$$

$$\rho_g = 1.66 \text{ lb/ft}^3.$$


$$q_{gsc} = 67824 * 10^{-6} * (24/12)^2 * 0.167 * [(50.02 - 1.66) / 1.66]^{0.5} (400 * 520 / 520 * 14.7)$$

$$q_{gsc} = 6.66 \text{ MM Scf/day}$$

2- Apply eq.(14) to determine oil capacity:

$$q_{or} = 100.7 * (2)^2 * 3.25 / 1 = 1309 \text{ bbl/day}$$

Figure (4-7) Estimate diameter of vertical separator.



Example (2):

Vertical separator has gas capacity = 100 MMcf/day, oil capacity = 7200 bbl/day, and operation pressure = 400 psi, API = 70°, t = 0.5 minute. What is the separator design (i.e. L & d)?

Solution:

1- Use figure (4-7) to determine d, by $p = 400$ psi, $API = 70^\circ$,
 $q_g = 100$ MMcf/day.
 $d = 72$ in $h_g = 2 d = 2 * 72 / 12 = 12$ ft

2- Use eq. (13) to calculate h_o :
 $7200 = 201.4 * (72/12)^2 h_o / 0.5$ $h_o = 0.5$ ft
 $L = h_g + h_o = 12 + 0.5 = 12.5$ ft.

Capacity of horizontal separators

1- Gas capacity

Total section area $A_t = (\pi/4) d^2$... (12)

Area of gas section = 1/2 total area

$$A_g = (\pi/8) d^2 \dots (13) \quad A_g = (\pi/4) d_e^2 \dots (14)$$

d = separator diameter

d_e = equivalent diameter

Substitute eq. (13) in eq. (14)

$$(\pi/8) d^2 = (\pi/4) d_e^2 \quad d_e = 0.5 d$$

$$q_{gsc} = 67824 * 10^{-6} d_e^2 c [(p_o - p_g) / p_g]^{0.5} (p T_{sc} / z T p_{sc}) (L/10)^{0.56} \dots (15)$$

L = height of separator, ft

2- Oil capacity

1- mono tube

$$q_o = 1440 V_o / 5.615 t \dots (16)$$

$$V_o = (\pi/4) (L/2) d^2 \dots (17)$$

Substitute eq. (17) in (16)

$$q_o = 100.7 (L d^2 / t) \dots (18)$$

d = inside diameter of separator, ft

L = height of separator, ft

q_o = oil capacity bbl/day

t = retention time, minute

And;

$$q_{or} = 50.35 (L d^2 / t) \dots (19)$$

q_{or} = rated oil capacity under separator condition bbl/day

2- dual tube

$$V_o = (\pi/4) L d^2 \dots (20)$$

$$q_o = 201.4 (L d^2/t) \dots (21)$$

$$q_{or} = 100.7 (L d^2/t) \dots (22)$$

Graphically the volume (size, d) of a horizontal separator can be estimated approximately, if the following data are known:

- 1- Operating pressure (psia)
 - 2- Oil gravity (API)
 - 3- Gas capacity (daily gas production, MMcf/day)
 - 4- Liquid residence volume, bbl
- and by figures (4-8) and (4-9), determine (d).

Example (3):

A mono tube horizontal separator has; $d = 24$ in, $L = 10$ ft, $p = 400$ psia, $T = 60$ °F, $c = 0.382$, $API = 35$, $\rho_g = 0.7$, $z = 0.909$, $t = 0.5$ minute. Calculate:

- 1- q_{or} when $t = 1$ minute.
- 2- d_e for gas section if $A_g = 0.5 A_t$.
- 3- q_{gsc} .

Solution:

1- Use eq. (19) to calculate q_{or} :

$$q_{or} = 50.35 (10 * (24/12)^2 / 1) = 2014 \text{ bbl/day}$$

2- Use eq. (14) to calculate d_e :

$$A_g = (\pi/4) d_e^2 \dots (14)$$

$$A_t = (\pi/4) d^2 = (\pi/4) (24/12)^2 = 3.142 \text{ ft}^2 \quad A_g = 0.5 A_t = 1.571 \text{ ft}^2$$

$$d_e = \sqrt{(4 A_g) / \pi} = \sqrt{(4 * 1.571) / \pi} = 1.414 \text{ ft}$$

3- Use eq. (15) to calculate q_{gsc} :

$$q_{gsc} = 67824 * 10^{-6} d_e^2 c [(\rho_o - \rho_g) / \rho_g]^{0.5} (p T_{sc} / z T p_{sc}) (L/10)^{0.56} \dots (15)$$

$$API = (141.5 / \rho_o) - 131.5$$

$$\text{Oil specific gravity, } \rho_o = 0.850 \quad \rho_o = \rho_o / \text{water}$$

$$\text{Oil density, } \rho_o = 62.4 * 0.850 = 53.03 \text{ lb/ft}^3.$$


$$\rho_g = p M_{w_{gas}} / zRT = p (M_{w_{air}} \rho_g) / zRT = 400 (0.7 * 29) / 0.909 * 10.73 * 520$$

$$\rho_g = 1.60 \text{ lb/ft}^3.$$

$$q_{gsc} = 67824 * 10^{-6} * (1.414)^2 * 0.0.382 * [(53.03 - 1.60) / 1.60]^{0.5} (400 * 520 / 0.909 * 520 * 14.7) (10/10)^{0.56}$$


$$q_{gsc} = 8.49 \text{ MM Scf/day}$$

Figure (4-8) Estimate gas capacity of horizontal separator.



HORIZONTAL SEPARATOR SIZING - ENGLISH UNITS

Figure (4-9) Estimate diameter of horizontal separator.



Example (4):

Horizontal separator has $q_g = 50$ MMcf/day, $q_o = 4320$ bbl/day, $p = 800$ psi, $API = 70^\circ$, and $t = 1$ minute. What is the separator design (i.e. L & d)?

Solution:

Use figure () to determine A_g , by $p = 800$ psi, $API = 70^\circ$,

$q_g = 50 \text{ MMcf/day}$.

$A_g = 5 \text{ ft}^2$

Use figure () to determine d , by $A_g = 5 \text{ ft}^2$, and $V_o = q_o * t = (4320*1)/1440$

$V_o = 3 \text{ bbl}$.

$d = 35 \text{ in}$, and $L = 4d = 4*35 = 140 \text{ ft}$.

Capacity of spherical separators

1- Gas capacity

Capacity of spherical separator depends on mist extractor capacity. Mist extractor diameter calculates by the following empirical equation;

$$d_m = 9.93 [Tz_g / p_o]^{0.25} (q_{gsc}/C)^{0.5} \dots(23)$$

d_m = mist extractor diameter, in

C = allow velocity constant (for screen slick mist extractor = 0.35)

q_{gsc} = gas flow rate (gas capacity), MMscf/day

2- Oil capacity

In this case the volume (V_o) of oil section equal to half total separator volume multiple to ($d/2$).

$$V_o = (\pi/12) (\overline{d/2})^3 \dots(24)$$

Where the actual oil capacity equal;

$$q_o = 1440V_o / 5.615t \dots(16)$$

substitute eq. (24) in (16)

$$q_o = 67.14 (\overline{d/2}) [d^3/t] \dots(25)$$

Also

$$q_{or} = 33.57 (\overline{d/2}) [d^3/t] \dots(26)$$

Example (5):

Calculate the Gas & Oil capacity for spherical separator, use the following data: $d = 30$ in, $\rho_g = 0.65$, $API = 45^\circ$, $p = 100$ psi,
 $T = 80$ °F, $t = 1$ minute. The gas behaves as ideal gas.

Solution:

1- Apply eq.(23) to determine gas capacity:

$$d_m = 9.93 [T \rho_g / p \rho_o]^{0.25} (q_{gsc}/C)^{0.5} \dots(23)$$

$$API = (141.5 / \rho_o) - 131.5$$

Oil specific gravity, $\rho_o = 0.8017$

Oil specific gravity, ρ_o at $T = 80$ °F equal:

$$\rho_o(T) = \rho_o(60) - \rho_o(60) * \rho_o(T - 60), \quad \rho_o = \text{extension oil volume factor} = 0.0005$$

$$\rho_o(80) = 0.8017 - 0.8017 * 0.0005 (80 - 60) = 0.7937$$

$$\rho_o = \rho_o / \rho_{\text{water}}$$

Oil density, $\rho_o = 62.4 * 0.7937 = 49.53$ lb/ft³.

$$\rho_g = p M_{w_{\text{gas}}} / zRT = p (M_{w_{\text{air}}} \rho_g) / zRT = 100 (0.65 * 29) / 1 * 10.73 * 540$$

$$\rho_g = 0.325 \text{ lb/ft}^3.$$

$$(30/2) = 9.93 [540 * 1 * 0.65 / 100 * 49.53]^{0.25} (q_{gsc}/0.35)^{0.5} \dots (23)$$

$$q_{gsc} = 3.00 \text{ MM Scf/day}$$

2- Apply eq.(26) to determine oil capacity:

$$q_{or} = 33.57 \left(\frac{d}{2} \right) [d^3/t] = 33.57 * \left(\frac{30}{12 * 2} \right) * [(30/2)^3/1]$$

$$q_{or} = 586 \text{ bbl/day}$$