

1.3. THE ANATOMY OF A CHEMICAL MANUFACTURING PROCESS

The basic components of a typical chemical process are shown in Figure 1.3, in which each block represents a stage in the overall process for producing a product from the raw materials. Figure 1.3 represents a generalised process; not all the stages will be needed for any particular process, and the complexity of each stage will depend on the nature of the process. Chemical engineering design is concerned with the selection and arrangement of the stages, and the selection, specification and design of the equipment required to perform the stage functions.




Figure 1.3. Anatomy of a chemical process

1.6. CODES AND STANDARDS

The need for standardisation arose early in the evolution of the modern engineering industry; Whitworth introduced the first standard screw thread to give a measure of interchangeability between different manufacturers in 1841. Modern engineering standards cover a much wider function than the interchange of parts. In engineering practice they cover:

1. Materials, properties and compositions.
2. Testing procedures for performance, compositions, quality.
3. Preferred sizes; for example, tubes, plates, sections.
4. Design methods, inspection, fabrication.
5. Codes of practice, for plant operation and safety.

The terms STANDARD and CODE are used interchangeably, though CODE should really be reserved for a code of practice covering say, a recommended design or operating procedure; and STANDARD for preferred sizes, compositions, etc.

1.6 CODES & STANDARDS

British Standards Institution (BSI)

American National Standards Institute (ANSI)

American Petroleum Institute (API)

American Society for Testing Materials (ASTM)

American Society of Mechanical Engineers (ASME)

(pressure vessels).

Burklin (1979) gives a comprehensive list of the American codes and standards.

The International Organisation for Standardisation (ISO) coordinates the publication of international standards.

1.7. FACTORS OF SAFETY (DESIGN FACTORS)

Design is an inexact art; errors and uncertainties will arise from uncertainties in the design data available and in the approximations necessary in design calculations. To ensure that the design specification is met, factors are included to give a margin of safety in the design; safety in the sense that the equipment will not fail to perform satisfactorily, and that it will operate safely: will not cause a hazard. "Design factor" is a better term to use, as it does not confuse safety and performance factors.

In mechanical and structural design, the magnitude of the design factors used to allow for uncertainties in material properties, design methods, fabrication and operating loads are well established. For example, a factor of around 4 on the tensile strength, or about 2.5 on the 0.1 per cent proof stress, is normally used in general structural design. The selection of design factors in mechanical engineering design is illustrated in the discussion of pressure vessel design in Chapter 13.

Design factors are also applied in process design to give some tolerance in the design. For example, the process stream average flows calculated from material balances are usually increased by a factor, typically 10 per cent, to give some flexibility in process operation.