



# DRILLING FLUIDS-2



Petroleum Well Drilling Engineering: Lec. 7

Dr. Mohammed Ali Alrashedi  
2024/2025

# DRILLING FLUIDS

## Basic Definition:

a mixture of clays, water, and chemicals pumped down the drill string while an oil well is being drilled to lubricate the mechanism, carry away rock cuttings, and maintain pressure so that oil or gas does not escape

## In other term

A drilling fluid, or mud, is any fluid that is used in a drilling operation in which that fluid is circulated or pumped from the surface, down the drill string, through the bit, and back to the surface via the annulus.

**Drilling mud** is one of the most important elements of any drilling operation.

The mud has a number of functions which must all be optimized to ensure safety and minimum hole problems. Failure of the mud to meet its design functions can prove extremely costly in terms of materials and time, and can also jeopardize the successful completion of the well and may even result in major problems such as stuck pipe, kicks or blowouts.

There are basically two types of drilling mud: water-based and oil-based, depending on whether the continuous phase is water or oil. Then there are a multitude of additives which are added to either change the mud density or change its chemical properties.

# Principal Functions of Drilling Fluids

The principal functions of the drilling fluid are:

- A. Subsurface pressure control
- B. Cuttings removal and transport
- C. Suspension of solid particle
- D. Sealing of permeable formations
- E. Stabilizing the wellbore
- F. Preventing formation damage
- G. Cooling and lubricating the bit and drill string
- H. Transmitting hydraulic horsepower to the bit
- I. Facilitating the collection of formation data
- J. Partial support of drill string and casing weight
- K. Controlling corrosion
- L. Assisting in cementing and completion

# 1-Subsurface pressure control

❖ The pore pressure depends on:

- The density of the overlying rock
- The pressure of the interstitial fluid
- Whether the rock is self supporting or is supported by the fluid.
- Tectonic activity
- Surface terrain

❖ If the fluid hydrostatic pressure does not balance the pore pressure the following may occur:

- Influxes of formation fluid into the wellbore
- Lost circulation
- Hole Instability
- Stuck pipe

## 2-Cuttings Removal and Transport

Circulation of the drilling fluid causes cuttings to rise from the bottom of the hole to the surface. Efficient cuttings removal requires circulating rates that are sufficient to override the force of gravity acting upon the cuttings. Other factors affecting the cuttings removal include drilling fluid density, annular velocity, hole angle, and cuttings-slip velocity.

In most cases, the rig hydraulics program provides for an annular velocity sufficient to result in a net upward movement of the cuttings. Annular velocity is determined by the cross-sectional area of the annulus and the pump output.

### 3-Suspension of Solid Particles

**When the rig's mud pumps are shut down and circulation is halted (e.g., during connections, trips or downtime), cuttings that have not been removed from the hole must be held in suspension.**

Otherwise, they will fall to the bottom (or, in highly deviated wells, to the low side) of the hole.

The rate of fall of a particle through a column of drilling fluid depends on the density of the particle and the fluid, the size of the particle, the viscosity of the fluid, and the thixotropic(gel-strength) properties of the fluid. The controlled gelling of the fluid prevents the solid particles from settling, or at least reduces their rate of fall. High gel strengths also require higher pump pressure to break circulation. In some cases, it may be necessary to circulate for several hours before a trip in order to clean the hole of cuttings and to prevent fill in the bottom of the hole from occurring during a round trip.

## 4-Sealing of permeable formation:

As the drill bit penetrates a permeable formation, the liquid portion of the drilling fluid filters into the formation and the solids form a relatively impermeable "cake" on the borehole wall. The quality of this filter cake governs the rate of filtrate loss to the formation.

Drilling fluid systems should be designed to deposit a thin, low permeability filter cake on the formation to limit the invasion of mud filtrate. This improves wellbore stability and prevents a number of drilling and production problems.

Potential problems related to thick filter cake and excessive filtration include "tight" hole conditions, poor log quality, increased torque and drag, stuck pipe, lost circulation and formation damage.

Bentonite is the best base material from which to build a tough, low-permeability filter cake.  
Polymers are also used for this purpose.



## 5-Stabilizing the Wellbore:

The borehole walls are normally competent immediately after the bit penetrates a section.

Wellbore stability is a complex balance of mechanical and chemical factors. The chemical composition and mud properties must combine to provide a stable wellbore until casing can be run and cemented. Regardless of the chemical composition of the fluid and other factors, the weight of the mud must be within the necessary range to balance the mechanical forces acting on the wellbore. The other cause of borehole instability is a chemical reaction between the drilling fluid and the formations drilled. In most cases, this instability is a result of water absorption by the shale. Inhibitive fluids (calcium, sodium, potassium, and oil-base fluids) aid in preventing formation swelling, but even more important is the placement of a quality filter cake on the walls to keep fluid invasion to a minimum.

## 6 -Preventing Formation Damage:

Any reduction in a producing formation's natural porosity or permeability is considered to be formation damage. If a large volume of drilling-fluid filtrate invades a formation, it may damage the formation and hinder hydrocarbon production.

**There are several factors to consider when selecting a drilling fluid:**

- ✓ **Fluid compatibility with the producing reservoir**
- ✓ **Presence of hydratable or swelling formation clays**
- ✓ **Fractured formations**
- ✓ **The possible reduction of permeability by invasion of nonacid soluble materials into the formation**

## 7 -Cooling and Lubricating the Bit:

Friction at the bit, and between the drill string and wellbore, generates a considerable amount of heat. The circulating drilling fluid transports the heat away from these frictional sites by absorbing it into the liquid phase of the fluid and carrying it away.

The laying down of a thin wall of "mud cake" on the wellbore aids in reducing torque and drag.

The amount of lubrication provided by a drilling fluid varies widely and depends on the type and quantity of drill solids and weight material, and also on the chemical composition of the system as expressed in terms of pH, salinity and hardness. Indications of poor lubrication are high torque and drag, abnormal wear, and heat checking of drill string components.

## 8 -Transmitting Hydraulic Horsepower to the Bit:

During circulation, the rate of fluid flow should be regulated so that the mud pumps deliver the optimal amount of hydraulic energy to clean the hole ahead of the bit. Hydraulic energy also provides power for mud motors to rotate the bit and for Measurement While Drilling (MWD) and Logging While Drilling (LWD) tools. Hydraulics programs are based on sizing the bit nozzles to maximize the hydraulic horsepower or impact force imparted to the bottom of the well.

## 9 -Facilitating the Collection of Formation Data:

The drilling fluid program and formation evaluation program are closely related. As drilling proceeds, for example, mud loggers monitor mud returns and drilled cuttings for signs of oil and gas. They examine the cuttings for mineral composition, paleontology and visual signs of hydrocarbons. This information is recorded on a mud log that shows lithology, penetration rate, gas detection and oil-stained cuttings, plus other important geological and drilling parameters.

Measurement-While-Drilling (**MWD**) and Logging-While-Drilling (**LWD**) procedures are likewise influenced by the mud program, as is the selection of wireline logging tools for post-drilling evaluation.

## 10 -Partial support of Drill String and Casing Weights:

With average well depths increasing, the weight supported by the surface wellhead equipment is becoming an increasingly crucial factor in drilling. Both drill pipe and casing are buoyed by a force equal to the weight of the drilling fluid that they displace. When the drilling fluid density is increased, the total weight supported by the surface equipment is reduced considerably.

## 11- Controlling corrosion

## 12 -Assistance in Cementing and Completion:

The drilling fluid must produce a wellbore into which casing can be run and cemented effectively, and which does not impede completion operations.

During casing runs, the mud must remain fluid and minimize pressure surges so that fracture-induced lost circulation does not occur. The mud should have a thin, slick filter cake. To cement casing properly, the mud must be completely displaced by the spacers, flushes and cement. Effective mud displacement requires that the hole be near-gauge and that the mud have low viscosity and low, non-progressive gel strengths. Completion operations such as perforating and gravel packing also require a near-gauge wellbore and may be affected by mud characteristics



**Thanks !**